

FAQ Maxwell - Manual NAT

Introduction

Manual NAT helps Maxwell devices to pass NAT gateways when the STUN request fails. The actual IP address of the Maxwell is replaced by the External IP address in all outgoing SIP messages.

- If 0.0.0.0 is specified, no IP address substitution is performed.
- If this parameter is specified, the Maxwell assumes this IP address when generating SIP messages and SDP (if NAT Mapping is enabled for that line) However, the results of STUN and VIA received parameter processing, if available, supersede this statically configured value. This option requires that you have
 1. a static IP address from your Internet Service Provider
 2. an edge device with a symmetric NAT mechanism.

Web-interface

In the web-interface go to: **SETTINGS - Telephony - Connections - Network Data of your Service Provider**

Network Data of your Service Provider

STUN

Yes

No

STUN server address

STUN Server port

3478

Manual NAT Address

0.0.0.0

STUN Refresh Time

25

sec.

Auto-provisioning

Parameter	Description
SIP.Account.x.STUN.ManualNAT	External IP address
Example:	
<pre><?xml version="1.0" encoding="UTF-8"?> <provisioning version="1.1" productID="mx3b"> <nvm> <param name="SIP.Account.0.STUN.Enabled" value="1"/> <param name="SIP.Account.0.STUN.Address" value="148.251.243.162"/> <param name="SIP.Account.0.STUN.Port" value="3478"/> <param name="SIP.Account.0.STUN.ManualNAT" value="0.0.0.0"/> <param name="SIP.Account.0.STUN.RefreshTimer" value="25"/> </nvm> </provisioning></pre>	