Interop T440 / T640 - VTX Telecom (FW Version 1.1.0)

VTX Switzerland

Feature	
Outgoing Calls	Yes
Incoming Calls	Yes
CLIP incoming	Yes
CLIP outgoing	Yes
Call Forwarding	Yes
Call Transfer	Yes
Call Waiting	Yes
DTMF	Yes
Anonymous Call	n/a
A-number forwarding	Yes

- VTX Switzerland

 Gigaset T440/T640 PRO settings.
 - Gateway Group
 - SIP gateway
 - Inbound routes
 - Outbound routes



Gigaset T440/T640 PRO settings.

For entering a new SIP trunk into the PBX, you need some steps:

- 1. Adding a new Gateway group
- 2. Adding a new SIP gateway
- 3. Defining the inbound routes (assignment of number to extension)
- 4. Defining the outbound routes

Gateway Group

In the Gigaset PBX go to "Administration" - "Routes" - "Gateway groups" enter a name for the new group and click on: Create new group

In the Gateway group you have to define the Outbound Caller ID, the Inbound DIDs (how the number is forwarded to the Inbound routes) and the Inbound caller ID (number presentation of external caller). in addition you can permit here inbound calls in general for this gateway group.

			Gigaset
Admi Admi ↑ Home ↑ Admi			Le Profile
Users & extensions >			
System >	Title	XTX	 Search/Replace pattern (PCRE) for outbound caller ID signalling. Examples: Extension only: s/*(*)/\$1/
Provisioning >	Permit inbound calls	ON	National format: s/*(*)/03012345681/ International format: s/*(*)/0493012345681/ or s/*(*)/+493012345681/ Same number for all users: s/*(*)/0493012345612/
Routes ~	Outbound caller ID	Search/replace pattern for outbound caller ID (1)	In most cases you should use the national or international format. (2) If necessary, specify here a PCRE-pattern which removes prefixes from inbound
Gateway groups		s/ ^(.*)	numbers, so that only the internal extension remains. Examples: s//026313370//
SIP gateways		/ \$1 /	s/*(((U049)U)2531)337U7) s/*(?.(?.0049)0)2631)73370(.*)/\$1/ (3) Search/Reniace pattern (PCRF) for inbound caller IDs to fix up eventually wrong
TDM Gateways	Asserted Identity	Search/replace pattern for asserted identity (1)	signalied caller IDs. Example: s/*/0/ or s/*(*)/0\$1/ to prefix the caller ID with a 0. Empty for no automatic change.
Inbound routes		s/	Experimental: This option can also be used to add or remove a leading 0 to/from call log entries by using $s/^{1}/0$ or $s/^{1}(s)/0$ or $s/^{0}(s)/1$.
Outbound routes		1	
Call forward	Inbound DIDs	Search/replace pattern to cut prefixes (2)	
System status		s/ ^(?:(?:(?:0032\\+32 32 0)?56)?032566142)?(*)	
		/ \$1 /	
	Inbound caller ID	Search/replace pattern for inbound caller ID (3)	
		\$/ ^(*)	
		/ \$1 /	
	Gateways	SIP - VTX	
	Outgoing caller IDs		
	Extension	Caller ID	
	101	0325661425	
	102	0325661426	
	Extension	Caller ID	
			Cancel Save

Outbound caller ID

As the number is fixed with this account, every user who is allowed to use this line will present the same number to the callee.

Asserted Identity

These fields are used specially for external forwardings. Some providers need special settings in order to present the correct number at the receiving party.

Inbound DIDs

For incoming calls, you can use the regular expression, generated by the setup assistant. In your case you would have to adjust the city-code and the first part of the extension, according to your line-settings.

Example: ^(?:(?:(?:0041|\+41|32|0)?56)?032566142)?(.*)

This will be forwarded to the Inbound Routes.

Inbound caller ID

For incoming calls, no additional **0** will be added.

Gateways

This field will be empty when you create this Gateway group. It will show later the assigned SIP gateways.

SIP gateway

In the Gigaset PBX go to "Administration" - "Routes" - "SIP gateways" enter a name for the new gateway and click on: Create new gateway

The SIP gateway contains all necessary data for the registration and dial command and how the number is delivered to/from the provider.

Just enter or choose the values according to your contract or data you received from the provider.

Example of VTX gateway settings 1/2.

			Gigaset
Adm Adm Adm Adm	inistration		👗 Profile
Users & extensions >	Title	VTX	(1) Empty for no proxy.
System >	Name	gw_1_vtx	(2) For some SIP providers, it might be neccessary to use the format user@domain. (domain is then used in the From header, which equals fromdomain in Asterisk.)
Provisioning >			(3) String for the Dial()-command. T440/T640 PRO will automatically replace (number) by
Routes ~	Hegistar	s1.259634.trk.ipvolp.ch	the called number, (number.1) without the first digit and (gateway) with the internal description of gw_1_amt.
Gateway groups	Proxy [1]	s1.259634.trk.ipvoip.ch	(4) In order to use gateways, they must be assigned to a gateway group.
SIP gateways	User [2]	4136000000000000000000000000000000000000	(5) When specifying the port (standard SIP port: 5060), it will be directly used. Without, a DNS lookup of the SRV record sig. udo of the domain (or server) will be performed upon
TDM Gateways	Password	Williams.	dialout. More Information Srv Resource Record, Srv Resource Record (en), CIDR, SIP-DNS- Srv-Records, SIP-DNS-Srv-Records (en), SIP-DNS-Srv-Records (en)
Inbound routes	Allow outhound calls	01	(6) Useful settings are e.g.
Outbound routes			0.0.0.0/0, to allow calls from all IP adresses, 192.0.2.0/24 to allow calls originating from network 192.0.2.*,
Call forward	Register	ON	192.168.0.0/16 to allow calls originating from network 192.168.**, 192.168.1.1/32 to allow calls originating from IP adress 192.168.1.1 etc.
System status >	Language	en - English (en-US)	(7) The priority of the codes is from left to right and top to bottom
	Dial comand [3]	SIP/{number}@(gateway)	
	Source of destination number	INVITE request line	
	Group [4]	VTX •	
	Port [5]	5060	
	NAT	yes 👻	
	Redirect RTP stream	Do not reroute RTP stream (default)	
	Check availability	01	
	Simultaneous calls	0 0 for unlimited (default)	
	DTFM mode	rfc2833 - RTP meta data	
	From user		
	From Domain		
	T38 support	OFF	-

Dial command

The dial command is the command which is used in the asterisk software. The term **{number:1**} means, that at the dialled number (e.g. 008987654321) the first digit is removed. If you don't use a line access code (in most cases '0' is used), you have to remove the '**:1**' !!! (Example is without access code)

<u>Group</u>

Select here the previously created gateway group.

Update remote party ID (CLIP)

This setting is just optional, as the provider replaces outgoing CLIP which is not valid with the default number of the SIP account.

For sending another CLIP, use the CLIP-No-Screening feature.

Advanced Parameter

Can be empty

Example of VTX gateway settings 2/2.

		Gıgi
Ad Home ► Menu O Ad	ninistration	
Users & extensions >	Insecure	port/invite - Options "port" and "invite"
System >	Update remote party ID (CLIP)	no - Deactivated (default)
Provisioning >		
Routes ~	Trust remote party ID	no-Deactivated (default)
Gateway groups	Codecs [7]	
SIP gateways		□ H.263+
TDM Gateways	Allowed IP subnet	0.000 / 0
Inbound routes		
Outbound routes	Advanced parameters	
Call forward	Value	
	Preview of peer in sip.conf [gw.1.vrd] type = peer hort = 1329343rk(pvojp.ch port = 3000 defaulture = 413 unboungshipy = 11299541rk(pvojp.ch thomodomain = unboungshipy = 11299541rk(pvojp.ch thomodomain = sentpd = n0 sector = 1000 rkt type = n0 instause = portunite sector = 1000 rkt type = n0 instause = n0 distingt = 0 distingt = 0	

Inbound routes

In the Gigaset PBX go to "Administration" - "Routes" - "Inbound routes" select the correct Gateway group and press Show.

									Gig	gaset
🔒 Home	dministration									👗 Profile
Users & extensions >										
System >	Inbound routes Night answer service									
Provisioning >	Inbound routes									
Routes ~										
Gateway groups	Gateway group	VTX (vtx)			•					
SIP gateways	Advanced options	OFF								
TDM Gateways		1								
Inbound routes	Rule	Number	Target	Profile			1			
Outbound routes	VTX	0041325661425	101		•					
Call forward	VTX 2	0041225661426	102		_	-				
System status >	11/22	0041323001420	102							
				-	•					
					_			 		
						,				,

Outbound routes

In the Gigaset PBX "Administration" - "Routes" - "Outbound routes" you don't have to activate the advanced options for the basic installation.

						G	igaset
A Home ► Menu	Administration						Let Profile
Users & extensions >							Î
System >	Outbound Routes						
Provisioning >							
Routes ~	Advanced options	OFF					
Gateway groups							
SIP gateways	Rule	Number	Gateway group				
TDM Gateways	VTX		VTX •	V			
Inbound routes			VTX -				
Outbound routes							
Call forward							
System status >							Save
							<u>.</u>