
FAQ - Syslog

Valid for:	N610	N670	N870	N870E	Embedded Integrator	Virtual Integrator

Introduction

The page contains the following information on incidents concerning DECT manager operation.

In the web-interface go to: **SETTINGS - System - System log**



Debug mode

The Debug mode is only used when it is known how to reproduce. When the logs are collected, the Debug mode must be disabled. The debug mode should only be used to collect logs for a short time.

Auto-provisioning

Parameter	Description
dm.local.SysLogEnable or dm.@.SysLogEnable	0: Off 1: On
dm.local.SysLogServer or dm.@.SysLogServer	**Server address:** Enter the IP address or the (fully qualified) DNS name of your Syslog server.
dm.local.SysLogServerPort or dm.@.SysLogServerPort	**Server port:** Enter the port number, where the Syslog server expects to receive requests.
dm.local.SysLogProtocol or dm.@.SysLogProtocol	**SyslogProtocol** • UDP • TCP • TLS
dm.local.SysLogTlsEnable or dm.@.SysLogTlsEnable	0: TLS Off 1: TLS On