

FAQ - Installation step by step for small and medium systems.

Valid for:	N640	N670	N870	N870E	Embedded Integrator	Virtual Integrator
------------	-----------------	------	------	-------	---------------------	--------------------

Introduction

Here you can find information about how to create a good installation planning to create an perfect functional multicell DECT system.

1. [Ask the customer for an building schematic or draw your own if none is available.](#)
2. [Collect information about the users location and phone behavior,](#)
3. [Define how many people should be able to call at the same time in which area.](#)
4. [Check for hotspots like meeting rooms and canteen.](#)
5. [Determine environmental conditions](#)
6. [Define the base stations positions](#)
7. [Determine sender positions and measuring points](#)
8. [Check the customer network set-up](#)
9. [Define the synchronization levels.](#)
10. [How many N870 devices do you need?](#)
11. [Base stations mounting instructions.](#)