FAQ - Installation step by step for small and medium systems.

Valid for:	~~N610~~	N670	N870	N870E	Embedded Integrator	Virtual Integrator

Introduction

Here you can find information about how to create a good installation planning to create an perfect functional multicell DECT system.

1. Ask the customer for an building schematic or draw your own if none is available.
2. Collect information about the users location and phone behavior,
3. Define how many people should be able to call at the same time in which area.
4. Check for hotspots like meeting rooms and canteen.
5. Determine environmental conditions
6. Define the base stations positions
7. Determine sender positions and measuring points
8. Check the customer network set-up
9. Define the synchronization levels.
10. How many N870 devices do you need?
11. Base stations mounting instructions.