

Maxwell 10 adb access

Introduction

Maxwell 10 has a mini USB port behind the left cradle cover. You can connect Maxwell via USB to your PC to upload data but also to access the adb interface.

Instruction

To get access to the adb interface, you have to activate USB debugging in the developer options.

Update drivers for "adb composite device" as well as "MTP" device drivers manually after connecting device to Windows PC.

Add "0x1e85" within file C:\Users\ininxxx\android\adb_usb.ini or copy attached adb_usb.ini file.

For linux please add "0x1e85" in /home/user/.android/adb_usb.ini



Unknown macro: 'widget'

Driver

- [adb_usb.zip](#)
- [gigaset_usb_driver_14032014.7z](#)
- [Introduction](#)
- [Instruction](#)
- [Driver](#)