

# Firmware Maxwell 10

## Updating firmware

Firmware updates can be downloaded from this page, so you can ensure your phone is always up to date. You can find the current version of your firmware on the Device status screen. You can update your phone automatically or manually. Any PC connected to the phone will not be able to access the local network and the Internet during the firmware update.

### There are 3 ways to upgrade your device.

Each way will take some minutes to finish the firmware upgrading, please pay attention to wait for success.

#### By Web GUI:

Go to: **Settings -> System -> Firmware Update**

Choose the file from hard-disk and Press <Load>




A screenshot of a web interface showing a text input field labeled "User-defined firmware file". The field contains the text "Bladeren..". To the right of the field is a button labeled "Load".

#### Internet update

Go to: **Settings -> System -> Firmware Update**

Select *Yes* for *Automatic check for software updates* and/or *Automatic check for profile updates*.

Enter the Web address for the automatic update search in the Data server field (Default = "profile.gigaset.net/device"). Click on Update firmware to start the search and to load the new firmware.



A screenshot of the "Firmware Update" settings screen. The screen has a dark background with white text. At the top, it says "Firmware Update". Below that, there is a "Data server" field with the text "http://profile.gigaset.net/dev" and a button labeled "Update firmware". Underneath the field, it says "...set custom url here". There are two sections of radio buttons: "Automatic check for software updates" with "Yes" selected, and "Automatic check for profile updates" with "No" selected. At the bottom, there are two buttons: "Save" and "Reset".

- [Maxwell 10 - beta releases](#)
- [Maxwell 10 - official releases](#)



**Maxwell 10**