

# Firmware DX800A

## Online update:

The firmware is online available.

You can easily initiate the update by three steps:

**Prerequisite:** The phone is connected to the Internet.

### Via the Handset:

1. Menu » Settings » System » Update Firmware
2. Enter base station system PIN (default setting: 0000)
3. Press the display key "Yes" to start the download

If your firmware is already up to date, the handset will inform you. No action is needed then.

### Via the webpage:


1. Settings » Management » Firmware update

## Manual update:

### Via the webpage:

1. Settings » Management » Firmware update
2. Enter the URL for the new firmware in the **User defined firmware file:** field
3. Click on the button: **Update firmware**

Network	<b>Firmware Update</b>	
Telephony	Data server:	<input type="text" value="profile.gigaset.net/device"/>
Messaging	User defined firmware file:	<input type="text"/>
Info Services	Automatic check for software updates:	<input checked="" type="radio"/> Yes <input type="radio"/> No
Directories	On starting the firmware update, the device checks if the requirements of a successful firmware download are fulfilled. The firmware is then downloaded without additional feedback. During the download and update, the handset / base connection is lost. A successful update results in the handset re-establishing the base connection.	
Management	<input type="button" value="Update firmware"/>	
Date & Time		
Local Settings		
Miscellaneous		
Reboot & Reset		
Save & Restore		
<b>Firmware Update</b>		



Software version 175

[Download](#)



Software version 173

[Download](#)

---



Software version 158

[Download](#)

---



Software version 131

[Download](#)

---