

# FAQ Maxwell - Web-UI Access


## Introduction

To reach the Web-UI of Maxwell you need to open a Browser and type in the IP address of the phone.

The IP address of the phone can be found in the phone menu at **Settings/Info**

**http://<ip-addr>**


You will be automatically redirected to the Login page.

 192.168.0.100/#/Login

To login to the Web-UI there are two different accounts available.

1. User Account  
To login as a user you need to type in the password **user**
2. Admin Account  
To login as a user you need to type in the password **admin**

Valid for Maxwell			
Basic	2	3	4



The user account cannot be used for connection setting. It is designed to allow customization of the phone by the user without changing crucial setting like SIP account, online phonebooks etc.