

FAQ Broadsoft XSI interface DE... desktop devices

Introduction

The BroadWorks Xtended Service Platform (XSP) enables a variety of ancillary interfaces on BroadWorks. The primary interface exposed by the XSP is the Xtended Services Interface (Xsi) – which provides a rich set of Web 2.0 interfaces for integrating BroadWorks services with desktop clients as well as Internet based applications.

Feature is available for:

- DE900/700 SW 02.00.11 or higher
- DE410/310 SW 02.00.08 or higher

Supported features are:

- Call forward Always
- Call forward Busy
- Call forward No Answer
- Do Not Disturb (DND)


Important

If you change it on the platform via the web-interface then the platform will not inform the device changes are made, therefore the device will not show the actual setting on the display. If you always use the phone to change the settings then it will show the correct settings on the display of the phone.

Configuration

In the web-interface of the device go to: **Settings - Server and Phone systems - Phone systems.**


Select "**Broadsoft**" as Phone system



In the web-interface of the device go to: **Settings - Telephony - Connections**

Open the Connection you are using for Broadsoft:

Enter the information you have received from your provider.



You can also change the Password direct from the device if needed.

Desktop devices auto provisioning parameters.

XML syntax:

```
<S_XSP_HOST class="string" value="http://<provider URL"/>
<S_XSP_USER class="string" value="Broadsoft user web-interface username"/>
<S_XSP_PW class="string" value="Broadsoft user web-interface password"/>
```

Tag Name	Value	Meaning
S_XSP_HOST	URL must be a valid URL like: http://<provider URL>	The URL to the Broadsoft XSI server

S_XSP_USER	XSI username	Broadsoft web-interface username
S_XSP_PW	XSI Password	Broadsoft web-interface Password

- [Introduction](#)
- [Configuration](#)
- [Desktop devices auto provisioning parameters.](#)