

FAQ Nx70 - Handset replacement via web-interface.

Introduction

If an handset needs to be replaced, the web-interface offers an **Replace** option.

In the web-interface go to: **SETTINGS - Mobile devices - Administration**

Select the handset and click on **Replace**.

Valid for:	
N670	N870

The screenshot shows the Gigaset web interface. The left sidebar contains a menu with 'Mobile devices' selected. The main content area displays a table of mobile devices. The table has columns for IPUI, Username, Display name, Location, DECT, SIP, Type, and FW. One device is listed with IPUI 029e74a599, Username 029e74a599, Display name Wernher VonBraun, Location local, DECT Registered, SIP checked, Type 'SL750H PRO', and FW 74.04. Below the table are buttons for '+ Add', 'Copy', 'Replace', 'Delete', 'Export', and 'Import'. Below the table is a 'Global settings' section with a radio button for 'Display name' selected.

A new window will open:

The screenshot shows the Gigaset web interface with the 'Mobile device' form open. The form has fields for IPUI, RegStatus (set to 'Not registered'), and Authentication Code (PIN) (set to '0000'). There is a 'Generate random PIN' button.

Enter the IPUI number of the new handset and press **Set** to save the changes.

The new handset must be registered to the system.