

FAQ Maxwell - Phone Web Server

Introduction

Open the web-interface of the Maxwell 3 / Basic and go to: **Settings - System - Phone Web Server**

The screenshot shows the 'Phone Web Server' configuration page. On the left is a dark navigation menu with 'SETTINGS' and 'STATUS' tabs. Under 'SETTINGS', there are categories: Network, Telephony, Online Directories, Online Services, Desk Phone, Web Configurator, and System (expanded to show 'Phone Web Server'). The main area is titled 'HTTP Server' and contains the following settings:

- HTTP Connection Type: HTTP + HTTPS (dropdown menu)
- HTTP port: 80 (input field)
- HTTPS port: 443 (input field)
- Automatic logout: 10 min. (input field)

Settings

Setting	Description
HTTP Connection Type	Select which HTTP connection for the Maxwell interface can be used HTTP HTTPS HTTP + HTTPS
HTTP port	Enter the number for the port to be used for communication via HTTP. The default setting is 80
HTTPS Port	Enter the number for the port to be used for communication via HTTPS. The default setting is 443
Automatic logout	Enter the time (minutes) after which an HTTP(S) connection should automatically end if no entries are made.

Auto provisioning

Parameter	Description
HTTP.ConnectionType	HTTP (Default) HTTPS HTTP_HTTPS
HTTP.Port	1 - 65535: 80 (Default)
HTTP.SecurePort	1 - 65535: 443 (Default)
WebUI.LogoutTimer	1 - 60: 10 (Default)