


DExxx - Call waiting tone

Call waiting tone

The Call waiting tone informs the user during an active call that there is a second call waiting to be answered.

For the Gigaset DE devices we made an improvement.



Go to: **Telephony** -> **Connections** -> Select your connection and press **Edit**.

You can use the setting:

- No call waiting tone.
- Only seen at display.
- Only one beep.
- A tone every 4 seconds.
- A tone every 10 seconds.
- A tone every 20 seconds.