


# FAQ Maxwell - Auto provisioning parameters

Valid for Maxwell			
Basic	2	3	4

<b>Web-interface: Settings - Network - IP</b>	
<b>IP</b>	
NET.General.DeviceNameInNetwork	a-z, A-Z, 0-9, -
<b>Address Assignment</b>	
NET.LAN.IP.DHCP.Enabled	0 = IP address type Static 1 = IP address type Dynamic (Default)
NET.IP.IPv4.Address	
NET.IP.IPv4.SubnetMask	
NET.IP.IPv4.StandardGateway	
NET.IP.IPv4.PreferredDNSServer	
NET.IP.IPv4.AlternateDNSServer	
<b>Web-interface: Settings - Network - LAN</b>	
<b>HTTP Proxy</b>	
NET.HTTP.ProxyServer.Active	0 = Enable proxy server No (Default) 1 = Enable proxy server Yes
NET.HTTP.ProxyServer.Address	
NET.HTTP.ProxyServer.Port	0 (Default) - 65535
<b>VLAN</b>	
NET.VLAN.Tagging	0 (Default) = off 1 = LAN 2 = LAN + PC
NET.VLAN.LAN.Identifier	
NET.VLAN.LAN.Priority	0 - 7
NET.VLAN.PC.Identifier	
NET.VLAN.PC.Priority	0 - 7
<b>Quality of Service (QoS)</b>	
NET.QoS.RTP.DSCP	0 - 64: 46 (Default)
NET.QoS.SIP.DSCP	0 - 64: 34 (Default)
<b>Link Layer Discovery Protocol (LLDP)</b>	
NET.LLDP.Active	0 = Disabled 1 = Enabled (Default)
NET.LLDP.PacketInterval	1 - 3600: 60 (Default)
<b>Web-interface: Settings - Telephony - VoIP</b>	
<b>SIP</b>	
SIP.TransportProtocol	1 = UDP (Default) 2 = TCP

SIP.Port	1 - 65535
SIP.Timers.T1	0 - 9999
SIP.Timers.Session	90 - 9999
SIP.Timers.FailedRegistration	0 - 9999
SIP.Timers.Subscription	0 - 9999
SIP.Timers.FailedSubscription	0 = Disabled 300 = Default
SIP.PRACK	0 = Disable 1 = Enabled
SIP.DisplayDiversionInfo.enable	0 = Do not show the Diversion Info 1 (Default) = Show the Diversion Info
<b>RTP</b>	
SIP.RTP.Port	1 - 65535: 5004 (Default)
SIP.RTP.UseRandomPorts	0 = Do not use random RTP ports 1 = Use random port from range <RTP.Port> - <RTP.Port+50> for RTP stream
SIP.RTP.UseSymmetricPorts	0 = Disable 1 = Enabled
SIP.RTP.UseRTCP	0 = Disable 1 = Enabled
SIP.RTP.UseRTCPXR	0 = Disable 1 = Enabled
SIP.RTP.RTCPXRServer.Address	RTCP XR server address
SIP.RTP.RTCPXRServer.Port	RTCP XR server port
<b>Security</b>	
SIP.Security.SRTP	0 = Disable 1 = Enabled
SIP.Security.AcceptNonSRTPCalls	0 = Disable 1 = Enabled
SIP.Security.UseSIPS	0 => TLS is disabled  1 => TLS is enabled, SIP scheme enabled  2 => TLS is enabled, SIPS scheme enabled
<b>Web-interface: Settings - Telephony - Connections</b>	
SIP.DefaultAccount	0 - 3 (4-5 Maxwell 4)
SIP.Accounts.Failover	0 = Do not use failover (default) 1 = Use failover
<b>IP Connection</b>	
SIP.Account.x.AccountName	
Maxwell B/2/3: x = 0 - 3 Maxwell 4: x = 0 - 5	
SIP.Account.x.Active	0 = Inactive 1 = Active
SIP.Account.x.Provider	
<b>Personal Provider Data</b>	
SIP.Account.x.AuthName	
SIP.Account.x.AuthPassword	
SIP.Account.x.DisplayName	

SIP.Account.x.Username	
<b>General Data of your Service Provider</b>	
SIP.Account.x.Domain	
SIP.Account.x.ProxyServer.Address	
SIP.Account.x.ProxyServer.Port	1 - 65535
SIP.Account.x.RegistrationServer.Address	
SIP.Account.x.RegistrationServer.Port	1 - 65535
SIP.Account.x.RegistrationServer.RefreshTimer	0 - 9999
<b>Redundancy</b>	
SIP.Account.x.DNSQuery	0 = A 1 = A + SRV
<b>Failover Server</b>	
SIP.Account.x.FailoverServer.Enabled	0 = Disabled 1 = Enabled
SIP.Account.x.FailoverServer.Address	
SIP.Account.x.FailoverServer.Port	
<b>Network Data of your Service Provider</b>	
SIP.Account.x.STUN.Enabled	0 = Disabled 1 = Enabled
SIP.Account.x.STUN.Address	
SIP.Account.x.STUN.Port	1 - 65535
SIP.Account.x.STUN.ManualNAT	IP address
SIP.Account.x.STUN.RefreshTimer	0 - 9999
SIP.Account.x.STUN.NATRefreshTimer	0 - 9999
SIP.Account.x.ICE	0 = Disabled 1 = Enabled
SIP.Account.x.OutboundProxy.Mode	0 = Always 1 = Auto 2 = Never
SIP.Account.x.OutboundProxy.Address	
SIP.Account.x.OutboundProxy.Port	1 - 65535
SIP.Account.x.DTMFTransmission Maxwell B/2/3: x = 0 - 3 Maxwell 4: x = 0 - 5	0 = Audio 1 = RFC 4733 2 = Audio + RFC 4733 3 = SIP info 4 = RFC 4733 + SIP info 5 = Audio + RFC 4733 + SIP info
IP.Account.x.AutoNegOfDTMFTransmission Maxwell B/2/3: x = 0 - 3 Maxwell 4: x = 0 - 5	0 = Automatic DTMF transmission disabled 1 = Automatic DTMF transmission enabled
SIP.Account.x.AllowRouteHeaders	0 = Switch off 1 = Switch on
<b>Display of Caller Information</b>	
SIP.Account.x.CLIPSource	0 = FROM 1 = PPI + FROM 2 = PAI + PPI + FROM 3 = RPID +FROM
<b>Web-interface: Settings - Telephony - Audio</b>	

Audio	
SIP.VoiceQuality	0 = Optimized for high bandwidth 1 = Optimized for low bandwidth 2 = Own codec preference  <div style="border: 1px solid green; border-radius: 10px; padding: 5px; display: inline-block;">  You need to use "2" Own codec preference to set available and active codecs.         </div>
SIP.ActiveCodecs	The codecs are sperated with a "," Example <param name="SIP.ActiveCodecs" value="8,9,0" /> 0 = uLaw 8 = aLaw 9 = g.722 18 = G.729 109 = iLBC 115 = g.726-32
SIP.RTP.Duration	20 30
SIP.G729.AnnexB	0 = Do not use Annex B (default) 1 = use Annex B
Web-interface: Settings - Telephony - Phone System	
Phone System	
Telephony.PhoneSystem.Type	0 = Standard (Default) 1 = Gigaset T640/T440 3 = Hybird 120 GE 4 = Starface 5 = Broadsoft (V2.11.x needed) 6 = Teles (2.21.x needed) 11 = Vodafone 13 = Vodia Peoplefone
Web-interface: Settings - Telephony - Phone System - Broadsoft	
BLF	
Telephony.PhoneSystem.BLFURL	Broadsoft BLF URL
Telephony.PhoneSystem.Broadsoft.BLF.AutomaticFKFilling.Enabled	0 = Manual Broadsoft BLF creation 1 = Automatic Broadsoft BLF creation
Telephony.PhoneSystem.Broadsoft.BLF.CallPickupCode	Broadsoft Call Pick up Feature code via blinking BLF key
Broadsoft services	
Telephony.PhoneSystem.XSI.Server	XSI Server URL
Telephony.PhoneSystem.XSI.SIPAuthentication	0 = XSI username and Password 1 = SIP authentication
Telephony.PhoneSystem.XSI.AuthName	XSI Username
Telephony.PhoneSystem.XSI.AuthPassword	XSI Password
Telephony.PhoneSystem.XSI.SearchAnywhereInName.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.Broadsoft.Lookup.Incoming	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.Broadsoft.Lookup.Outgoing	0 = Disabled 1 = Enabled
Personal	
Telephony.PhoneSystem.XSI.PersonalDirectory.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.XSI.PersonalDirectory.Name	Name of the personal Directory

<b>Group</b>	
Telephony.PhoneSystem.XSI. GroupDirectory.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.XSI. GroupDirectory.Name	Name of the Group Directory
<b>Group Common</b>	
Telephony.PhoneSystem.XSI. GroupCommonDirectory.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.XSI. GroupCommonDirectory.Name	Name of the Group Common Directory
<b>Enterprise</b>	
Telephony.PhoneSystem.XSI. EnterpriseDirectory.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.XSI. EnterpriseDirectory.Name	Name of the Enterprise Directory
<b>Enterprise Common</b>	
Telephony.PhoneSystem.XSI. EnterpriseCommonDirectory.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.XSI. EnterpriseCommonDirectory.Name	Name of the Enterprise Common Directory
<b>Call log</b>	
Telephony.PhoneSystem.XSI.CallLogType	0 = Basic Call log 1 = Enhanced Call log
<b>Automatic Call Distribution (ACD)</b>	
Telephony.PhoneSystem.Broadsoft.ACD. Enabled	0 = ACD Disabled 1 = ACD Enabled
Telephony.PhoneSystem.Broadsoft.ACD. Status	0 = Agent un-available after login 1 = Agent available after login
<b>Flexible Seating</b>	
Telephony.PhoneSystem.Broadsoft. FlexibleSeating.Enabled	0 = Disabled 1 = Enabled
<b>Web-interface: Settings - Telephony - Call Settings</b>	
<b>Call Transfer</b>	
Telephony.CallTransfer. AutoDetermineAddress	Enabled Disabled
Telephony.CallTransfer. SemiAttendedTransferType	0 = Early attended 1 = Semi-attended
Telephony.CallTransfer.HoldOnTransfer. Attended	Enabled Disabled
Telephony.CallTransfer.HoldOnTransfer. Unattended	Enabled Disabled
Telephony.CallTransfer. DeriveTargetAddress	sipurl, sipcontact
<b>Access Code</b>	
Telephony.AccessCode.Code	Access code

Telephony.AccessCode.Enabled	Not used
Telephony.AccessCode.For	0 = Never 1 = For directories 2 = For call lists 3 = For directories and Call lists 4 = Always
Telephony.AccessCode.InternalNumberLength	Set the length for internal numbers 0 - 9
<b>Area Codes</b>	
Telephony.AreaCodes.Country	Other,ALB,ARG,AUS,AUT,BHR,BLR,BEL,BOL,BIH,BRA,BGR,CAN,CHL,CHN,COL,CRI,HRV,CYP,CZE,DNK,ECU,EGY,EST,FIN,FRA,DEU,GRC,HKG,HUN,ISL,IND,IDN,IRN,IRL,ISR,ITA,JPN,JOR,KWT,LVA,LBN,LIE,LTU,LUX,MKD,MYS,MEX,MNE,MAR,NAM,NLD,NZL,NOR,PAK,PSE,PAN,PRY,PER,PHL,POL,PRT,PRI,ROU,RUS,SAU,SRB,SGP,SVK,SVN,ZAF,KOR,ESP,SWE,CHE,TWN,THA,TUR,ARE,GBR,USA,URY,VEN,VNM
Telephony.AreaCodes.Int.Prefix	
Telephony.AreaCodes.Int.Code	
Telephony.AreaCodes.Local.Prefix	
Telephony.AreaCodes.Local.Code	
<b>Tone Selection</b>	
Telephony.ToneScheme	INT,AUT,CAN,CZE,DNK,EGY,FIN,FRA,DEU,GRC,NLD,POL,PRT,ROU,ZAF,RUS,SAU,SVK,ESP,SWE,CHE,ARE,GBR,USA,ITA
Telephony.DialTone.Enabled	0 = Disabled 1 = Enabled
<b>Call Waiting</b>	
SIP.Account.0-3.CallWaiting	0 = Disabled 1 = Enabled
SIP.Account.0-3.CallWaitingSignal	Off SingleBeep BeepEvery4 BeepEvery10 BeepEvery20
WebUI.CallSettings.CallWaiting.Disable	Hide Call waiting in Web-UI
<b>Count Calls / Voicemails</b>	
SIP.Account.0-3.CountMissedAcceptedCalls	0 = Missed calls disabled 1 = Missed call enabled (default)
<b>Count Calls / Voicemails</b>	
Telephony.Speechpath.CallsViaCallManager	0 = No 1 = Headset 2 = Handsfree
Telephony.Speechpath.IncCallsWithoutCallManager	0 = No 1 = Headset 2 = Handsfree
Telephony.Speechpath.OutCallsViaFunctionKey	1 = Headset 2 = Handsfree
<b>Call Pickup Group</b>	
Telephony.CallPickupGroup.Enabled	0 = Disabled 1 = Enabled
Telephony.CallPickupGroup.Code	
Telephony.CallPickupGroup.Ringtone	
Telephony.CallPickupGroup.RingingMode	0,1,2
Telephony.CallPickupGroup.SubscribedAccount	

**Web-interface: Settings - Telephony - Call Divert****All Calls**

Telephony.CallDivert.0-3.All.Active	0 = Disabled 1 = Enabled
Telephony.CallDivert.0-3.All.VoiceMail	0 = Disabled 1 = Enabled
Telephony.CallDivert.0-3.All.Target	Phonenumber where all calls are diverted to.  Telephony.CallDivert.0-3.All.VoiceMail should be set to 0 to use this feature.

**When Busy**

Telephony.CallDivert.0-3.Busy.Active	0 = Disabled 1 = Enabled
Telephony.CallDivert.0-3.Busy.VoiceMail	0 = Disabled 1 = Enabled
Telephony.CallDivert.0-3.Busy.Target	Phonenumber where all calls are diverted to when device is busy.  Telephony.CallDivert.0-3.Busy.VoiceMail should be set to 0 to use this feature.

**No Answer**

Telephony.CallDivert.0-3.NoAnswer.Active	0 = Disabled 1 = Enabled
Telephony.CallDivert.0-3.NoAnswer.Delay	5,10,15,20,25,30,45,60,90,120 (Default)
Telephony.CallDivert.0-3.NoAnswer.VoiceMail	0 = Disabled 1 = Enabled
Telephony.CallDivert.0-3.NoAnswer.Target	Phonenumber where all not answered calls are diverted to.  Telephony.CallDivert.0-3.Busy.VoiceMail should be set to 0 to use this feature.
WebUI.CallDivert.Disable	Hide Call Divert from Web-UI 0 = Disabled 1 = Enabled

**Web-interface: Settings - Telephony - Do not Disturb****Do not Disturb**

Telephony.DnD.Active	0 = Disabled 1 = Enabled
Telephony.DnD.List.Active	0 = Disabled 1 = Enabled
Telephony.DnD.List.0-49.Name	
Telephony.DnD.List.0-49.Number	
Telephony.DnD.AnonymousCallBlock	0 = Disabled 1 = Enabled

**Web-interface: Settings - Telephony - Dialling Plans****Dialling Plans**

Telephony.DiallingPlans.List.0-19.Number	
Telephony.DiallingPlans.List.0-19.UseAreaCode	0 = Disabled 1 = Enabled
Telephony.DiallingPlans.List.0-19.Connection	
Telephony.DiallingPlans.List.0-19.Comment	
Telephony.DiallingPlans.List.0-19.Active	0 = Disabled 1 = Enabled

**Call Barring**

Telephony.CallBarring.List.0-19.Number	
Telephony.CallBarring.List.0-19.Comment	
Telephony.CallBarring.List.0-19.Blocked	0 = Disabled 1 = Enabled
<b>Web-interface: Settings - Telephony - Phone Lock</b>	
See: <a href="#">FAQ Maxwell - Locking/unlocking the keypad / Emergency numbers</a>	
<b>Web-interface: Settings - Telephony - Voicemail</b>	
<b>Voicemail</b>	
SIP.Account.0-3.VoiceMail.Active	0 = Disabled 1 = Enabled
SIP.Account.0-3.VoiceMail.Mailbox	
<b>Web-interface: Settings - Online Directories - LDAP</b>	
<b>LDAP Directory</b>	
NetDir.LDAP.0.DirectoryName	
NetDir.LDAP.0.Enable	0 = Disabled 1 = Enabled
NetDir.LDAP.0.Lookup	0 = Disabled 1 = Enabled  It works only if the LDAP directory is enabled.
<b>Access to the LDAP Data Server</b>	
NetDir.LDAP.0.Server.Address	
NetDir.LDAP.0.Server.Port	1 - 65535
NetDir.LDAP.0.BaseDN	
NetDir.LDAP.0.Username	
NetDir.LDAP.0.Password	
NetDir.LDAP.0.ResponseTimeout	1 - 10
NetDir.LDAP.0.Security	0 = Off 1 = TLS start 2 = LDAPS
<b>Search in LDAP Data Base</b>	
NetDir.LDAP.0.NameFilter	
NetDir.LDAP.0.NumberFilter	
NetDir.LDAP.0.DisplayFormat	
NetDir.LDAP.0.MaxNumberOfSearchResults	
NetDir.LDAP.0.FirstName	
NetDir.LDAP.0.Surname	
NetDir.LDAP.0.PhoneHome	
NetDir.LDAP.0.PhoneOffice	
NetDir.LDAP.0.PhoneMobile	
NetDir.LDAP.0.Email	
NetDir.LDAP.0.Fax	
NetDir.LDAP.0.Company	
NetDir.LDAP.0.Street	



NetDir.LDAP.0.City	
NetDir.LDAP.0.ZIP	
NetDir.LDAP.0.Country	
NetDir.LDAP.0.AdditionalAttribute	
NetDir.LDAP.0.AdditionalAttributeDialable	Yes No
<b>Web-interface: Settings - Online Directories - XML</b>	
Directory via XML protocol	
NetDir.Xml.0.ProviderName	
NetDir.Xml.0.ServerAddress	
NetDir.Xml.0.Username	
NetDir.Xml.0.Password	
NetDir.Xml.0.NumberFilter	bp
NetDir.Xml.0.LookupIncomming	0 = Disabled 1 = Enabled
NetDir.Xml.0.LookupOutgoing	0 = Disabled 1 = Enabled
Private Online Directory	
NetDir.Xml.0.EnablePrivateDirectory	0 = Disabled 1 = Enabled
NetDir.Xml.0.PrivateDirectoryName	
White Pages	
NetDir.Xml.0.EnableWhiteDirectory	0 = Disabled 1 = Enabled
NetDir.Xml.0.WhiteDirectoryName	
Yellow Pages	
NetDir.Xml.0.EnableYellowDirectory	0 = Disabled 1 = Enabled
NetDir.Xml.0.YellowDirectoryName	
<b>Web-interface: Settings - Online Services - Doorstation</b>	
Door Station	
NetSrv.DoorStations.0-19.Name	
NetSrv.DoorStations.0-19.SIPID	
NetSrv.DoorStations.0-19.DTMFCode	
NetSrv.DoorStations.0-19.Username	
NetSrv.DoorStations.0-19.Password	
NetSrv.DoorStations.0-19.CameraURL	This parameter is ignored by Maxwell 2
NetSrv.DoorStations.0-19. PictureRefreshTime	Time in msec, see below for the allowed values.  500 = 2 fps 200 = 5 fps 100 = 10 fps 67 = 15 fps  This parameter is ignored by Maxwell 2
<b>Web-interface: Settings - Desk Phone - Main Menu</b>	

Main Menu																																																																																								
System.MainMenu.Content	Standard (Default) User defined																																																																																							
Web-interface: Settings - Desk Phone - Ringtones																																																																																								
Ringtones																																																																																								
SIP.DefaultRingtone	For values, see list below.																																																																																							
SIP.Account.0-3.Ringtone.External	<p>06_Gigaset.mp3 (or .wav)</p> <p>Attention: Full-path will be optional from version 2.19.x. Then the filename will be sufficient to set the ringtone. Until version 2.18.4 the full path is still necessary.</p> <table border="1"> <thead> <tr> <th>Name in UI/Web-UI</th> <th>Filename</th> <th>From software 2.24.12</th> </tr> </thead> <tbody> <tr><td>01</td><td>01.wav</td><td>01.mp3 (or .wav)</td></tr> <tr><td>02_Memo</td><td>02_Memo.wav</td><td>02_Memo.mp3 (or .wav)</td></tr> <tr><td>03_Vibe</td><td>03_Vibe.wav</td><td>03_Vibe.mp3 (or .wav)</td></tr> <tr><td>04_Listen</td><td>04_Listen.wav</td><td>04_Listen.mp3 (or .wav)</td></tr> <tr><td>05_Down</td><td>05_Down.wav</td><td>05_Down.mp3 (or .wav)</td></tr> <tr><td>06_Gigaset</td><td>06_Gigaset.wav</td><td>06_Gigaset.mp3 (or .wav)</td></tr> <tr><td>07_Egg</td><td>07_Egg.wav</td><td>07_Egg.mp3 (or .wav)</td></tr> <tr><td>08_Peak</td><td>08_Peak.wav</td><td>08_Peak.mp3 (or .wav)</td></tr> <tr><td>09_Step</td><td>09_Step 3.wav</td><td>09_Step 3.mp3 (or .wav)</td></tr> <tr><td>10_P Cut</td><td>10_P Cut.wav</td><td>10_P Cut.mp3 (or .wav)</td></tr> <tr><td>11_Set</td><td>11_Set.wav</td><td>11_Set.mp3 (or .wav)</td></tr> <tr><td>12_Sim</td><td>12_Sim.wav</td><td>12_Sim.mp3 (or .wav)</td></tr> <tr><td>13_Tone one</td><td>13_Tone one.wav</td><td>13_Tone one.mp3 (or .wav)</td></tr> <tr><td>14_Dunken</td><td>14_Dunken.wav</td><td>14_Dunken.mp3 (or .wav)</td></tr> <tr><td>15_Piano</td><td>15_Piano.wav</td><td>15_Piano.mp3 (or .wav)</td></tr> <tr><td>16_Officebuffer</td><td>16_Officebuffer.wav</td><td>16_Officebuffer.mp3 (or .wav)</td></tr> <tr><td>17_Twelve</td><td>17_Twelve.wav</td><td>17_Twelve.mp3 (or .wav)</td></tr> <tr><td>18_Flightzone</td><td>18_Flightzone.wav</td><td>18_Flightzone.mp3 (or .wav)</td></tr> <tr><td>19_Waste</td><td>19_Waste.wav</td><td>19_Waste.mp3 (or .wav)</td></tr> <tr><td>20_Smooth G</td><td>20_Smooth_G.wav</td><td>20_Smooth_G.mp3 (or .wav)</td></tr> <tr><td>21_Green Tea</td><td>21_Green Tea.wav</td><td>21_Green Tea.mp3 (or .wav)</td></tr> <tr><td>22_Evolve 1</td><td>22_Evolve 1.ogg</td><td>Evolve 1.ogg</td></tr> <tr><td>23_Evolve 2</td><td>23_Evolve 2.ogg</td><td>Evolve 2.ogg</td></tr> <tr><td>Bellcore 1</td><td>bellcore_dr1.ogg</td><td>bellcore_dr1.ogg</td></tr> <tr><td>Bellcore 2</td><td>bellcore_dr2.ogg</td><td>bellcore_dr2.ogg</td></tr> <tr><td>Bellcore 3</td><td>bellcore_dr3.ogg</td><td>bellcore_dr3.ogg</td></tr> <tr><td>Bellcore 4</td><td>bellcore_dr4.ogg</td><td>bellcore_dr4.ogg</td></tr> <tr><td>Bellcore 5</td><td>bellcore_dr5.ogg</td><td>bellcore_dr5.ogg</td></tr> </tbody> </table>	Name in UI/Web-UI	Filename	From software 2.24.12	01	01.wav	01.mp3 (or .wav)	02_Memo	02_Memo.wav	02_Memo.mp3 (or .wav)	03_Vibe	03_Vibe.wav	03_Vibe.mp3 (or .wav)	04_Listen	04_Listen.wav	04_Listen.mp3 (or .wav)	05_Down	05_Down.wav	05_Down.mp3 (or .wav)	06_Gigaset	06_Gigaset.wav	06_Gigaset.mp3 (or .wav)	07_Egg	07_Egg.wav	07_Egg.mp3 (or .wav)	08_Peak	08_Peak.wav	08_Peak.mp3 (or .wav)	09_Step	09_Step 3.wav	09_Step 3.mp3 (or .wav)	10_P Cut	10_P Cut.wav	10_P Cut.mp3 (or .wav)	11_Set	11_Set.wav	11_Set.mp3 (or .wav)	12_Sim	12_Sim.wav	12_Sim.mp3 (or .wav)	13_Tone one	13_Tone one.wav	13_Tone one.mp3 (or .wav)	14_Dunken	14_Dunken.wav	14_Dunken.mp3 (or .wav)	15_Piano	15_Piano.wav	15_Piano.mp3 (or .wav)	16_Officebuffer	16_Officebuffer.wav	16_Officebuffer.mp3 (or .wav)	17_Twelve	17_Twelve.wav	17_Twelve.mp3 (or .wav)	18_Flightzone	18_Flightzone.wav	18_Flightzone.mp3 (or .wav)	19_Waste	19_Waste.wav	19_Waste.mp3 (or .wav)	20_Smooth G	20_Smooth_G.wav	20_Smooth_G.mp3 (or .wav)	21_Green Tea	21_Green Tea.wav	21_Green Tea.mp3 (or .wav)	22_Evolve 1	22_Evolve 1.ogg	Evolve 1.ogg	23_Evolve 2	23_Evolve 2.ogg	Evolve 2.ogg	Bellcore 1	bellcore_dr1.ogg	bellcore_dr1.ogg	Bellcore 2	bellcore_dr2.ogg	bellcore_dr2.ogg	Bellcore 3	bellcore_dr3.ogg	bellcore_dr3.ogg	Bellcore 4	bellcore_dr4.ogg	bellcore_dr4.ogg	Bellcore 5	bellcore_dr5.ogg	bellcore_dr5.ogg
Name in UI/Web-UI	Filename	From software 2.24.12																																																																																						
01	01.wav	01.mp3 (or .wav)																																																																																						
02_Memo	02_Memo.wav	02_Memo.mp3 (or .wav)																																																																																						
03_Vibe	03_Vibe.wav	03_Vibe.mp3 (or .wav)																																																																																						
04_Listen	04_Listen.wav	04_Listen.mp3 (or .wav)																																																																																						
05_Down	05_Down.wav	05_Down.mp3 (or .wav)																																																																																						
06_Gigaset	06_Gigaset.wav	06_Gigaset.mp3 (or .wav)																																																																																						
07_Egg	07_Egg.wav	07_Egg.mp3 (or .wav)																																																																																						
08_Peak	08_Peak.wav	08_Peak.mp3 (or .wav)																																																																																						
09_Step	09_Step 3.wav	09_Step 3.mp3 (or .wav)																																																																																						
10_P Cut	10_P Cut.wav	10_P Cut.mp3 (or .wav)																																																																																						
11_Set	11_Set.wav	11_Set.mp3 (or .wav)																																																																																						
12_Sim	12_Sim.wav	12_Sim.mp3 (or .wav)																																																																																						
13_Tone one	13_Tone one.wav	13_Tone one.mp3 (or .wav)																																																																																						
14_Dunken	14_Dunken.wav	14_Dunken.mp3 (or .wav)																																																																																						
15_Piano	15_Piano.wav	15_Piano.mp3 (or .wav)																																																																																						
16_Officebuffer	16_Officebuffer.wav	16_Officebuffer.mp3 (or .wav)																																																																																						
17_Twelve	17_Twelve.wav	17_Twelve.mp3 (or .wav)																																																																																						
18_Flightzone	18_Flightzone.wav	18_Flightzone.mp3 (or .wav)																																																																																						
19_Waste	19_Waste.wav	19_Waste.mp3 (or .wav)																																																																																						
20_Smooth G	20_Smooth_G.wav	20_Smooth_G.mp3 (or .wav)																																																																																						
21_Green Tea	21_Green Tea.wav	21_Green Tea.mp3 (or .wav)																																																																																						
22_Evolve 1	22_Evolve 1.ogg	Evolve 1.ogg																																																																																						
23_Evolve 2	23_Evolve 2.ogg	Evolve 2.ogg																																																																																						
Bellcore 1	bellcore_dr1.ogg	bellcore_dr1.ogg																																																																																						
Bellcore 2	bellcore_dr2.ogg	bellcore_dr2.ogg																																																																																						
Bellcore 3	bellcore_dr3.ogg	bellcore_dr3.ogg																																																																																						
Bellcore 4	bellcore_dr4.ogg	bellcore_dr4.ogg																																																																																						
Bellcore 5	bellcore_dr5.ogg	bellcore_dr5.ogg																																																																																						
SIP.Account.0-3.Ringtone.HeaderExternal	<http://www.notused.com>;info=alert-external																																																																																							
SIP.Account.0-3.Ringtone.Internal	See: SIP.Account.0-3.Ringtone.External																																																																																							

SIP.Account.0-3.Ringtone.HeaderInternal	<http://www.notused.com>;info=alert-internal
SIP.Account.0-3.Ringtone.Group	See: SIP.Account.0-3.Ringtone.External
SIP.Account.0-3.Ringtone.HeaderGroup	<http://www.notused.com>;info=alert-group
SIP.Account.0-3.Ringtone.Doorstation	See: SIP.Account.0-3.Ringtone.External
SIP.Account.0-3.Ringtone.HeaderDoorstation	<http://www.notused.com>;info=alert-door
SIP.Account.0-3.Ringtone.Optional	See: SIP.Account.0-3.Ringtone.External
SIP.Account.0-3.Ringtone.HeaderOptional	
<b>Web-interface: Settings - Desk Phone - Display (Depends on phone type if supported)</b>	
<b>Display</b>	
PhoneUI.Settings.Language	en-us (Default)  de-de  fr-fr  es-es  it-it  nl-nl  tr-tr  pt-pt  el-gr  da-dk  sv-se  no-no  cs-cz  pl-pl  sl-sl  ro-ro  ru-ru
PhoneUI.Settings.ScreenSaverTimeout	0,10,20 (Default),30,40,50,60
PhoneUI.Settings.ColorScheme.Tree	(Maxwell 3): 0 - White on Black (see main screen then) 1 - White on Blue (see main screen then) 2 - White on Red (see main screen then) 3 - White on Green (see main screen then)  This parameter is ignored by Maxwell 2
PhoneUI.Settings.ColorScheme.Basic	(Maxwell Basic): 4 - White on Black (see main screen then) 5 - Black on White (see main screen then)
PhoneUI.Settings.Backlight	1 - 9: 7 (Default)
PhoneUI.Settings.Contrast	1 - 9: 5 (Default)
PhoneUI.Settings.BacklightTimeout	1 - 120: 5 (Default): Value is in minutes
PhoneUI.Settings.ScreenSaverSelection	0 = Analog clock 1 = Digital clock 2 = Pictures 3 = HTTP source Maxwell 2 only supports values 0 and 1

PhoneUI.Settings.ScreenSaverHTTPSource	This parameter is ignored by Maxwell 2
PhoneUI.Settings.SelectedWallpapers	<b>Only Maxwell 4:</b> See <a href="#">FAQ Maxwell - Background picture.</a>
<b>Night Mode</b>	
IsNightModeEnabled	0 = Disabled 1= Enabled
NightModeStartTime	Start time in format: HH:MM
NightModeEndTime	End time in format: HH:MM
IsNightModeSilencingCalls	0 = Disabled 1= Enabled
<b>Web-interface: Settings - Desk Phone - Message Notification</b>	
<b>Visual Call Notification (LED)</b>	
Telephony.VoiceMail.VoicemailMessages.Active	0 = Disabled 1 = Enabled
Calls.Missed.Notification.Active	0 = Disabled 1 = Enabled
<b>SIP Notification</b>	
PhoneUI.SIP.ShowSIPMessagesOnDisplay	0 = Disabled 1 = Enabled
PhoneUI.SIP.ClearSIPMessageWithBackKey	0 = Disabled 1 = Enabled
<b>Web-interface: Settings - Desk Phone - Keys and LEDs</b>	
<b>Programmable Keys</b>	
PhoneUI.Keys.ProgrammableKeys.Center.Type	0 = Default 1 = XHTML
PhoneUI.Keys.ProgrammableKeys.CallLog.Type	0 = Default 1 = XHTML
PhoneUI.Keys.ProgrammableKeys.Directory.Type	1 = LDAP 3 = XML white pages 4 = Local directory 5 = XML yellow pages 6 = XML Private directory 7 = XSI Personal 8 = XSI Group 9 = XSI Group Common 10 =XSI Enterprise 11 = XSI Enterprise Common 12 = XHTML
PhoneUI.Keys.ProgrammableKeys.Messages.Type	0 = Default 1 = FAC 2 = Action URL 3 = XHTML
PhoneUI.Keys.ProgrammableKeys.Messages.FAC	
PhoneUI.Keys.ProgrammableKeys.Messages.ActionURL	
PhoneUI.Keys.ProgrammableKeys.DND.Type	0 = Default 1 = FAC 2 = Action URL = XHTML

PhoneUI.Keys.ProgrammableKeys.DND.FAC.enable	
PhoneUI.Keys.ProgrammableKeys.DND.FAC.disable	
PhoneUI.Keys.ProgrammableKeys.DND.ActionURL.enable	
PhoneUI.Keys.ProgrammableKeys.DND.ActionURL.disable	
PhoneUI.Keys.ProgrammableKeys.Hold.Type	0 = Default 1 = DTMF code 2 = Action URL
PhoneUI.Keys.ProgrammableKeys.Hold.DTMFCode	
PhoneUI.Keys.ProgrammableKeys.Hold.ActionURL	
PhoneUI.Keys.ProgrammableKeys.Conference.Type	0 = Default 1 = DTMF code 2 = Action URL 3= FAC
PhoneUI.Keys.ProgrammableKeys.Conference.DTMFCode	
PhoneUI.Keys.ProgrammableKeys.Conference.ActionURL	
PhoneUI.Keys.ProgrammableKeys.Conference.FAC	
<b>Soft Keys</b>	
PhoneUI.Keys.SoftKeys.X.Type  Maxwell B/ 2/ 3 / 4 X=0 Left SoftKey, X=1 Right Softkey  Maxwell 4 X = 2 and X = 3 for the Soft keys in the middle	-1 = No function 3 = Quick Dial 5 = SIP URL 8 = Action URL 9 = SIP INFO 10 = FAC 11 = Call Waiting 12 = Local Directory 13 = Ldap Directory 14 = Xml Public 15 = Xml Yellow 16 = Xml Private 17 = Redial 18 = Select Line 22 = XSI Personal Directory 23 = XSI Group Common Directory 24 = XSI Group Directory 25 = XSI Enterprise Common Directory 26 = XSI Enterprise Directory
PhoneUI.Keys.SoftKeys.X.Action  X = 0 - 3	Only Valid for: <ul style="list-style-type: none"><li>SIP INFO</li></ul>
PhoneUI.Keys.SoftKeys.X.Connection  X = 0 - 3	Only Valid for: <ul style="list-style-type: none"><li>Quick Dial</li></ul>
PhoneUI.Keys.SoftKeys.X.DisableCode  X = 0 - 3	Only Valid for: <ul style="list-style-type: none"><li>FAC</li></ul>

PhoneUI.Keys.SoftKeys.X.DisableName X = 0 - 3	Only Valid for: <ul style="list-style-type: none"> <li>SIP INFO</li> <li>FAC</li> </ul>
PhoneUI.Keys.SoftKeys.X.EnableCode X = 0 - 3	Only Valid for: <ul style="list-style-type: none"> <li>FAC</li> </ul>
PhoneUI.Keys.SoftKeys.X.EnableName X = 0 - 3	Only Valid for: <ul style="list-style-type: none"> <li>Quick Dial</li> <li>SIP URI</li> <li>Action URL</li> <li>SIP INFO</li> <li>FAC</li> </ul>
PhoneUI.Keys.SoftKeys.X.PhoneNumber X = 0 - 3	Only Valid for: <ul style="list-style-type: none"> <li>Quick Dial</li> </ul>
PhoneUI.Keys.SoftKeys.X.URL X = 0 - 3	Only Valid for: <ul style="list-style-type: none"> <li>SIP URI</li> <li>Action URL</li> </ul>
SoftKeys.X.Active X = 0 - 3	0 = When SoftKey is FAC then change to disabled 1 = When SoftKey is FAC then change to enabled  It will only change the key status, the device does not send the FAC.
<b>Quick Dial Keys</b>	
PhoneUI.Keys.QuickDialKeys.X.Type x = 1,2,3,4	0 - Default 1 - QuickDial 2 - FAC 3 - ActionURL
PhoneUI.Keys.QuickDialKeys.X.Number x = 1,2,3,4	0 - Default 1 - QuickDial 2 - FAC 3 - ActionURL
PhoneUI.Keys.QuickDialKeys.X.FAC x = 1,2,3,4	0 - Default 1 - QuickDial 2 - FAC 3 - ActionURL
PhoneUI.Keys.QuickDialKeys.X.ActionURL x = 1,2,3,4	0 - Default 1 - QuickDial 2 - FAC 3 - ActionURL
<b>Function keys (Only Maxwell 3)</b>	
<b>Function Keys - Configuration</b>	
Telephony.ShowKeysDisplayName	0 = Disabled 1 = Enabled
PhoneUI.Keys.FunctionKeys.Icons	0 = Do not show Function key icons 1 = Show Function key icons (Default)
PhoneUI.Keys.FunctionKeys.Indicator	0 = Thin 1 = Bold
<b>Function Keys - Idle Screen</b>	

<p>PhoneUI.Keys.FunctionKeys.X.Type</p> <p><b>Maxwell 2 and 3:</b> X = (Function key) 0 - 7</p> <p>Expansion module 1 level 1: X = (Function key) 8 - 36 Expansion module 1 level 2: X = (Function key) 37 - 65</p> <p>Expansion module 2 level 1: X = (Function key) 66 - 94 Expansion module 2 level 2: X = (Function key) 95 - 123</p> <p>Expansion module 3 level 1: X = (Function key) 124 - 152 Expansion module 3 level 2: X = (Function key) 153 - 181</p> <p><b>Maxwell 4:</b> X = (Function key) 0 - 37</p> <p>Expansion module 1 level 1: X = (Function key) 38 - 66 Expansion module 1 level 2: X = (Function key) 67 - 95</p> <p>Expansion module 2 level 1: X = (Function key) 96 - 124 Expansion module 2 level 2: X = (Function key) 125 - 153</p> <p>Expansion module 3 level 1: X = (Function key) 154 - 182 Expansion module 3 level 2: X = (Function key) 183 - 211</p>	<p>-1 (No Function)</p> <p>0 (Line, not for Expansion module)</p> <p>1 (Shared Line, not for Expansion module)</p> <p>2 (Park + Retrieve, not for Expansion module)</p> <p>3 (Quick Dial)</p> <p>4 (BLF)</p> <p>5 (SIP URI)</p> <p>6 (Call Divert, not for Expansion module)</p> <p>7 (DTMF)</p> <p>8 (Action URL)</p> <p>9 (SIP INFO)</p> <p>10 (FAC)</p>
<p>PhoneUI.Keys.FunctionKeys.X.DisplayName</p> <p>Maxwell 2, 3 and 4: X = (Function key) 0 - 7</p>	<p>0-9, a-z, A-Z, *, @ , etc.</p>
<p>PhoneUI.Keys.FunctionKeys.X.Connection</p> <p>Maxwell 2, 3 and 4: X = (Function key) 0 - 7</p>	<p>SIP account 0 (1) - 3 (4)</p> <p>Valid for:</p> <ul style="list-style-type: none"> <li>• Line</li> <li>• Shared Line</li> <li>• Park and Retrieve</li> <li>• Quick Dial</li> <li>• BLF</li> <li>• Call Divert</li> <li>• SIP Info</li> </ul>
<p>PhoneUI.Keys.FunctionKeys.X.PhoneNumber</p> <p>Maxwell 2, 3 and 4: X = (Function key) 0 - 7</p>	<p>Valid for:</p> <ul style="list-style-type: none"> <li>• Park and Retrieve</li> <li>• Quick Dial</li> <li>• BLF</li> <li>• Call Divert</li> </ul>
<p>PhoneUI.Keys.FunctionKeys.X.CallPickupCode</p> <p>Maxwell 2, 3 and 4: X = (Function key) 0 - 7</p>	<p>Valid for:</p> <ul style="list-style-type: none"> <li>• BLF</li> </ul>
<p>PhoneUI.Keys.FunctionKeys.X.URL</p> <p>Maxwell 2, 3 and 4: X = (Function key) 0 - 7</p>	<p>Valid for:</p> <ul style="list-style-type: none"> <li>• SIP URI</li> <li>• Action URI</li> </ul>
<p>PhoneUI.Keys.FunctionKeys.X.CallDivertType</p> <p>Maxwell 2, 3 and 4: X = (Function key) 0 - 7</p>	<p>Valid for:</p> <ul style="list-style-type: none"> <li>• Call Divert</li> </ul>

PhoneUI.Keys.FunctionKeys.X.EnableCode Maxwell 2, 3 and 4: X = (Function key) 0 - 7	Valid for: <ul style="list-style-type: none"> <li>• DTMF</li> <li>• FAC</li> </ul>
PhoneUI.Keys.FunctionKeys.X.DisableCode Maxwell 2, 3 and 4: X = (Function key) 0 - 7	Valid for: <ul style="list-style-type: none"> <li>• FAC</li> </ul>
PhoneUI.Keys.FunctionKeys.X.DTMFCode Maxwell 2, 3 and 4: X = (Function key) 0 - 7	Available in Maxwell 3 and 4 Valid for: <ul style="list-style-type: none"> <li>• DTMF</li> </ul>
PhoneUI.Keys.FunctionKeys.X.Action Maxwell 2, 3 and 4: X = (Function key) 0 - 7	Valid for: <ul style="list-style-type: none"> <li>• SIP INFO</li> </ul>
PhoneUI.Keys.FunctionKeys.X.Color Maxwell 2, 3 and 4: X = (Function key) 0 - 249	"0" -> Red "1" -> Green "2" -> Yellow "3" -> Standard  This parameter is ignored by Maxwell 2 for the main-device keys. Only expansion module keys can be used with multi-color.
<b>Function keys for expansion module</b> see <a href="#">here</a>	
<b>Web-interface: Settings - Desk Phone - Events</b>	
<b>URL Links for Events</b>	
System.Events.RegistrationSucceeded	
System.Events.RegistrationFailed	
System.Events.ConnectionEstablished	
System.Events.ConnectionTerminated	
System.Events.OffHook	
System.Events.OnHook	
System.Events.IncomingCall	
System.Events.OutgoingCall	
<b>Web-interface: Settings - Desk Phone - Local Phonebook</b> <a href="#">See wiki article</a>	
<b>Load Phonebook from URL</b>	
System.LocalPhonebook.Url	
System.LocalPhonebook.UpdateTime	08:00
<b>Display</b>	
System.LocalPhonebook.Name	
PhoneUI.Directory.Local.SearchAnywhere	0 = No 1 = Yes
PhoneUI.Directory.Local.NameFirst	0 = Surname, Name 1 = Name, Surname
<b>Web-interface: Settings - Web Configurator</b>	
WebUI.AdminPassword	
WebUI.UserPassword	
WebUI.ShowPassword	



WebUI.AllowAccessWeb	0 = Allow access from a different subnet 1 = No access from different subnet (Default)
<b>Web-interface: Settings - System - Phone Web Server</b>	
<b>HTTP Server</b>	
HTTP.ConnectionType	HTTP (Default) HTTPS HTTP_HTTPS
HTTP.Port	1 - 65535: 80 (Default)
HTTP.SecurePort	1 - 65535: 443 (Default)
WebUI.LogoutTimer	1 - 60: 10 (Default)
<b>Web-interface: Settings - System - Provisioning and Configuration</b>	
PhoneUI.Provisioning. ShowInProgressOnDisplay  (Parameter is not in web-interface)	0 = Do not show "Provisioning in Progress" on Display. 1 = Show "Provisioning in Progress" on Display. (Default)
<b>Auto Provisioning</b>	
System.Provision.ProvisioningServer	<a href="http://profile.gigaset.net/device/%DVID/">http://profile.gigaset.net/device/%DVID/</a> (Default)
<b>Web-interface: Settings - System - Firmware Update</b>	
<b>Firmware Update</b>	
FirmwareManagment. AutomaticCheckForUpdates	0 = Automatic check for updates is "No" 1 = Automatic check for updates is "Yes"
System.Provision.Period  (Parameter is not in web-interface)	0 (Default) = Random value between 1:00 and 4:00 am  Minimum time is 600 seconds. If you configure the time <600 and > 0 then it can be that during manual testing provisioning, the device will wait until the 600 seconds are passed and with the correct setting this will not happen.  Maximum time is 86400 seconds
<b>Web-interface: Settings - System - Security</b>	
System.Security.AcceptAllCertificates	0 = Accept all certificates No (Default) 1 = Accept all certificates Yes
System.Security.HTTPAuthUsername	
System.Security.HTTPAuthPassword	
<b>Web-interface: Settings - System - Date and Time</b>	
System.DateAndTime.AutoAdjustTime (Updated in the 2.22 software or higher)	NTPServiceDisabled = Setting "Local" in web-interface, time is set manually. NTPServiceEnabled = NTP server via provisioning, if not send then use DHCP option 42 NTPServiceManual = NTP server is entered manually via the web-interface. NTPServiceDHCP = Use DHCP option 42, if not send then use NTP server via provisioning.
System.DateAndTime.TimeServer	pool.ntp.org (Default)

System.DateAndTime.TimeZone

GMT+1.Europe/Amsterdam

GMT-11.Pacific/Midway  
GMT-10.Pacific/Honolulu  
GMT-9.America/Anchorage  
GMT-8.America/Los\_Angeles  
GMT-8.America/Tijuana  
GMT-7.America/Phoenix  
GMT-7.America/Chihuahua  
GMT-7.America/Denver  
GMT-6.America/Costa\_Rica  
GMT-6.America/Chicago  
GMT-6.America/Mexico\_City  
GMT-6.America/Regina  
GMT-5.America/Bogota  
GMT-5.America/New\_York  
GMT-4.America/Barbados  
GMT-4.America/Halifax  
GMT-4.America/Manaus  
GMT-3.America/Sao\_Paulo  
GMT-3.America/Argentina/Buenos\_Aires  
GMT-3.America/Godthab  
GMT-3.America/Montevideo  
GMT-3.America/Santiago  
GMT-2.Atlantic/South\_Georgia  
GMT-1.Atlantic/Azores  
GMT-1.Atlantic/Cape\_Verde  
GMT.Africa/Casablanca  
GMT.Europe/London  
GMT+1.Europe/Amsterdam  
GMT+1.Europe/Belgrade  
GMT+1.Europe/Brussels  
GMT+1.Europe/Sarajevo  
GMT+1.Africa/Brazzaville  
GMT+1.Africa/Windhoek  
GMT+2.Asia/Amman  
GMT+2.Europe/Athens  
GMT+2.Asia/Beirut  
GMT+2.Africa/Cairo  
GMT+2.Africa/Harare  
GMT+2.Europe/Helsinki  
GMT+2.Asia/Jerusalem  
GMT+3.Asia/Baghdad  
GMT+3.Asia/Kuwait  
GMT+3.Europe/Minsk  
GMT+3.Europe/Moscow  
GMT+3.Africa/Nairobi  
GMT+4.Asia/Baku  
GMT+4.Asia/Dubai  
GMT+4.Asia/Tbilisi  
GMT+4.Asia/Yerevan  
GMT+5.Asia/Karachi  
GMT+5.Asia/Oral  
GMT+5.Asia/Yekaterinburg  
GMT+6.Asia/Almaty  
GMT+7.Asia/Bangkok  
GMT+7.Asia/Krasnoyarsk  
GMT+8.Asia/Shanghai  
GMT+8.Asia/Hong\_Kong  
GMT+8.Asia/Irkutsk  
GMT+8.Asia/Kuala\_Lumpur  
GMT+8.Australia/Perth  
GMT+8.Asia/Taipei  
GMT+9.Asia/Seoul  
GMT+9.Asia/Tokyo  
GMT+9.Asia/Yakutsk  
GMT+10.Australia/Brisbane  
GMT+10.Pacific/Guam  
GMT+10.Australia/Hobart  
GMT+10.Asia/Magadan  
GMT+10.Australia/Sydney  
GMT+10.Asia/Vladivostok  
GMT+12.Pacific/Auckland  
GMT+12.Pacific/Fiji  
GMT+12.Pacific/Majuro  
GMT+13.Pacific/Tongatapu

System.DateAndTime. AutoAdjustClockForDST	AutomatedDaylightSavingDisabled AutomatedDaylightSavingEnabled
System.DateAndTime.TimeFormat	12h 24h (Default)
System.DateAndTime.DateOrder	dd.mm.yyyy (Default) mm.dd.yyyy
System.DateAndTime.NTPDns	Not in web-interface: Enable/disable PTR queries for NTP NTPDnsEnabled NTPDnsDisabled
<b>Web-interface</b>	
WebUI.Language	en-us (Default)  de-de  fr-fr  es-es  it-it  nb-no  nl-nl  tr-tr  pt-pt  el-gr  da-dk  sv-se  cs-cz  pl-pl  sl-sl  ro-ro  ru-ru  hu-hu  bg-bg  hr-hr  sr-rs  sq-al
WebUI.ShowPIN	0 = Show PIN No 1 = Show PIN Yes (Default)
PhoneUI.Security.PIN	1234 (Default)
<b>Device settings not available via web-interface</b>	
<b>Phone UI</b>	
PhoneUI.Settings.Volume	1 - 10: 5 (Default)  Menu - Settings - Audio - Ringtones -Volume

PhoneUI.Settings.Confirmations	0 (Default) Menu - Settings - Audio - Advisory Tones - Confirmations
PhoneUI.Settings.KeyClick	0 (Default) Menu - Settings - Audio - Advisory Tones - Key Click
PhoneUI.Settings.AnonymousCallSilencing	Menu - Settings - Audio - Ringtones - Anonymous Call Silencing
PhoneUI.Audio.ReceiverVolume	1 - 10: 3 (Default)
PhoneUI.Audio.HeadsetVolume	1 - 10: 3 (Default)
PhoneUI.Audio.HandsfreeVolume	1 - 10: 3 (Default)
PhoneUI.SelectedServices.Disable	0 = Show Selected Services menu in PhoneUI (Default) 1 = Hide Selected Servicesmenu in PhoneUI
Telephony.ShowKeysDisplayName	0 = No 1 = Yes
PhoneUI.ActiveRingbacks.Disable	0 = Show Active Ringbacks menu item in PhoneUI (Default) 1 = Hide Active Ringbacks menu item in PhoneUI
PhoneUI.Audio.OneMelody.Doorstation	
PhoneUI.Audio.OneMelody.External	
PhoneUI.Audio.OneMelody.Group	
PhoneUI.Audio.OneMelody.Internal	
PhoneUI.Audio.OneMelody.Optional	
PhoneUI.CallDivert.Disable	0 = Show Call Divert menu item in PhoneUI (Default) 1 = Hide Call Divert menu in PhoneUI
PhoneUI.CallWaiting.Disable	0 = Show Call Waiting menu item in PhoneUI (Default) 1 = Hide Call Waiting menu in PhoneUI
PhoneUI.Directory.Local.NameFirst	
PhoneUI.Menu.Contacts.Visible	0 = Hide Contacts menu in PhoneUI 1 = Show Contacts menu in PhoneUI (Default)
PhoneUI.WithholdNumber.Disable	0 = Show Withhold Number menu item in PhoneUI (Default) 1 = Hide Withhold Number menu item in PhoneUI
<b>WEB-UI</b>	
WebUI.CallSettings.CallWaiting.Disable	0 = Show Call waiting menu in Web-UI (Default) 1 = Hide Call waiting in Web-UI
WebUI.CallDivert.Disable	0 = Show Call Divert menu in Web-UI (Default) 1 = Hide Call Divert menu in Web-UI  Note: It will also enable/disable the function key Call Divert.
<b>Others</b>	
PhoneUI.Settings.DistinctiveRinging	1 (Default) = Show all ringtones in MMI and web-interface 0 = Hide the Distinctive ringtones (External, Internal, Group, Doorstation) in MMI and web-interface. Used when provider does not support Distinctive ringtone.
<a href="#">SIP.Checksync.Simple</a>	0 (default) = Device will not reboot automatic after check-sync. If reboot=true is send then of course device will reboot 1 = Device will reboot automatic after check-sync. (same behavior as reboot=true is send) If device will receive reboot=false then also reboot will happen.  Timer 1 only provisioning is done: Device will reboot 5 seconds after downloading provisioning file Timer 2 also firmware update is started: Device will reboot 90 seconds after firmware file is downloaded.  (Device will not allow a reboot during these 90 seconds, it waits until the 90 seconds are passed)
Calls.Missed.Subscribe.Active	0 = inactive - Subscribe for MWI is <b>not</b> send to server, MWI displayed correctly 1 = active (default) - Subscribe for MWI is send to server, MWI displayed correctly

SoftKeys.X.Active X=0 Left SoftKey, X=1 Right Softkey	0 = When SoftKey is FAC then change to disabled 1 = When SoftKey is FAC then change to enabled
SIP.Account.(0-3).RegistrationServer. ReregisterAlternative	0 (Default) = Disabled, SIP re-REGISTER 50% of the negotiated expire timer. 1 = Enabled, SIP re-REGISTER 75% of the negotiated expire timer.
NetDir.LookupCacheValidationTime	adjustable lookup cache validation time  0 = buffer entries 1 = ask every lookup, 2 = refresh after 15min, 3 = refresh after 1h, 4 = refresh after 6h, 5 = refresh after 12h, 6 = refresh after 18h, 7 = refresh after 1day, 8 = refresh after 2days, 9 = refresh after 3days, 10 = refresh after 5days, 11 = refresh after 1week
<b>Web-interface: Expert - Network - Switch Settings</b>	
<b>Switch Settings</b>	
NET.SwitchSettings.EnablePortMirroring	Enable port mirroring: 0 = Disabled 1 = Enabled
NETWORK.SwitchSettings. LinkSpeedDuplexLanPort	Link speed and duplex mode - LAN Port  Autonegotiation 10 Mbit Half-Duplex 10 Mbit Full-Duplex 100 Mbit Half-Duplex 100 Mbit Full-Duplex 1000 Mbit Full-Duplex
NETWORK.SwitchSettings. LinkSpeedDuplexPcPort	Link speed and duplex mode - PC Port  Autonegotiation 10 Mbit Half-Duplex 10 Mbit Full-Duplex 100 Mbit Half-Duplex 100 Mbit Full-Duplex 1000 Mbit Full-Duplex Disabled
NET.SwitchSettings.AllowFragmentation	Allow fragmentation of frames 0 = Disabled 1 = Enabled
<b>Web-interface: Expert - Network - DHCP Settings</b>	
<b>DHCP Settings</b>	
NET.IP.IPv4.DHCP.Options.Disabled	43, 66, 114, 120
<b>Web-interface: Expert - Audio - Adjustment</b>	
<b>Adjustment</b>	
Audio.Adjustment.EnableAec	Enable AEC handset mode Yes = Enabled No = Disabled
<b>MIC Level TX</b>	
Audio.Adjustment.HandsetMode	Handset microphone TX level 0 - 10
Audio.Adjustment.HandsFreeMode	Handsfree microphone TX level 0 - 10
Audio.Adjustment.HeadsetMode	Headset microphone TX level 0 - 10
<b>Web-interface: Expert - Debugging - System Logging</b>	
<b>Reboot</b>	

System.QA.AutomaticReboot.Enabled	0 = Disabled 1 = Enabled
System.QA.AutomaticReboot.Weekdays	Monday = 1 Tuesday = 2 Wednesday = 4 Thursday = 8 Friday = 16 Saturday = 32 Sunday = 64 Example: Monday AND Friday AND Sunday = 1 + 16 + 64 = 81
System.QA.AutomaticReboot.Time	Time in the following format HH:MM example: 15:44
<b>System Logging</b>	
System.Syslog.RemoteLogging.Enabled	Activate Remote Syslog 0 = Disabled 1 = Enabled
System.Syslog.RemoteLogging.Server	Syslog server IP address
System.Syslog.RemoteLogging.Port	Syslog server port (514)
<b>Web-interface: Expert - Debugging -Advanced Settings</b>	
System.AllowHTTPOutgoing	0 = Disabled 1 = Enabled
SIP.Notify.AcceptInvalidCSeq	Accept Invalid CSeq 0 = Disabled 1 = Enabled
System.Security.RemoteControl.Allow	0 = Disabled 1 = Enabled
System.Security.RemoteControl.Source	Remote Control Source
System.Provision.Multicast.Allow	Active SIP Multicast
SIP.Multicast.Active	
System.General.RemoveUASpecialChars	Remove special characters 0 = Disabled 1 = Enabled