

FAQ Nx70 - Messaging "4 Title"

Introduction

The "title" is the

- First line of the message
- First line of the message when opening the message list



The title:

- Send by the message server via the MQTT interface (Example: "title":{"text":"Fire detected !!!"},)
- Up to 18 characters, depends on the handset
- When more characters are send, the text is cut on the right side