

FAQ Maxwell - DHCP Settings

Introduction

Open the web-interface of the Maxwell and go to the Expert page by changing the URL in the web-browser: **/Expert/Network/DHCP Settings**

Here you can disable the following DHCP options.

- DHCP 43
- DHCP 66
- DHCP 114
- DHCP 120


Valid for Maxwell

Basic

2

3

4



Auto provisioning

Parameter	Description
NET.IPv4.DHCP.Options.Disabled	43,66,114,120 single value or separated via "," Empty then all DHCP options are enabled.
Example: <code><param name="NET.IPv4.DHCP.Options.Disabled" value="43,66"/></code>	