

Baudisch

Baudisch the SIP station is supported Gigaset PBX v5.2. Operating in a model with CP-CAM video module is possible. Both devices can be configured manually.

Important Note:

Gigaset only supports the commissioning of the SIP component of the station. Any additional questions for the assembly of the station, installation of relay or switch functions and further, or safety-relevant components is not answered by Gigaset Support (phone or e-mail). The manufacturers documentation and firmware must be confirmed directly by Baudisch. For more information, please visit the manufacturer web site (see below) or the manufacturer's documentation.



Conceptual and preparation of Gigaset PBX

- The SIP station and CP-CAM are two independent IP terminals. Both devices require each a separate IP address and must be configured separately.
- The SIP station is configured in the Gigaset PBX as a SIP phone with the SIP profile 'Baudisch Door Station'.
 - The username is freely chosen, e.g. baudisch.sip
 - Please create a password automatically with the random-function of the PBX.
 - Also a DTMF sequence can be stored convenience feature to trigger a switching function (e.g. open the door).
- The CP-CAM is configured as a property of the SIP phone.
 - The URL to the image of the CP-CAM is:

`http:// <IP-address CP-CAM> / jpg / image.jpg`

Konfiguration

Editieren

Benutzer

Gruppen

Telefone

Module

Voicemail

Konferenz

Adressbuch

Rufnummern

Leitungen

Routing

Server

Auswertung

Anlagenverbund

Sicherheit

Erweiterte Einstellungen

Detailldaten **Konfiguration der SIP Zugangsdaten**

Art des Endgerätes: Funktionalität:

Telefonname: Passwort:

Verwendete Serveradresse: 192.168.32.133 Letzte bekannte Geräte-IP: 192.168.32.159

Autoprovisionierung

Letzte Provisionierung: 01.01.1970 00:00:00

MAC-Adresse: ---

Firmware-Version: ---

Telefoneinstellungen überschreiben:

Erweiterte Einstellungen

NAT:

Codecs:

IP-Beschränkung:

Türsprechstelle

Einschalten Ausschalten

Kamera-URL:

DTMF:

Konfiguration der URL zur CP-CAM sowie der DTMF Sequenz für Schaltfunktionen

- The SIP phone is now assigned to a dedicated user. This can be named as desired, e.g. First name: Door; Name: Entrance
 - The telephone-numbers of the user also allow calls to this station. This must be unlocked separately in the station.
 - By the user-assignment the doorstation get the right to make external calls.
 - It is recommended for those users to deactivate the right "Phone Log".

Benutzer: Erdgeschoss, Tür

Angezeigte Rufnummer: Primäres Telefon:

Anklopfen: aktivieren Ruhe:

Gerätename	Rufnummer klingelt	Aktiv
▼ SIP/baudisch.sip		<input checked="" type="checkbox"/>
	198	<input checked="" type="checkbox"/>

- The Baudisch SIP intercom calls internal or external numbers when pressing the ringing-button.
 - In general, the target should be a group (Group Strategy: Ring All), in the example with group number 199.
 - All participants in this group of the Gigaset PBX are notified accordingly if the ringing-button on the Baudisch SIP doorstation is pressed.
 - **Note:** The combination with a module 'Group with Waiting-queue' is currently not supported.

Gruppe: Sammelruf Türe

Gruppenspezifische Einstellungen

Gruppenspezifische Einstellungen

Gruppenname:

Klingelstrategie:

Gruppen ID: Passwort:

Chateinstellungen

Chatgruppe:

Gruppenspezifische Einstellungen

Primäre interne Rufnummer:

Primäre externe Rufnummer:

Rufnummer

199	X
-----	---

+

Gruppenspezifische Einstellungen

Liste der Gruppenmitglieder

Benutzer	Angemeldet
1. Kirk, James T.	<input checked="" type="checkbox"/> X
2. Chekov, Pavel	<input checked="" type="checkbox"/> X

+

Configuring SIP station

Important Note:

Please follow carefully the instructions of the manufacturer's documentation for setup. Please also note that you must save the setting changes separately on each page.

Configuration actions

Phone book

The settings of the phone book within the SIP station define the destination numbers within the Gigaset PBX which should be called if the ringing-button is pressed. There are various settings available here. Here is a simple standard scenario described.

The central call configures the behavior of the station when you press the ringing-symbol without the use of the arrow keys. Depending on the model of the SIP station, further configuration may be required.

- Central phone (display text)
 - Name: Idle-display on the bell display in three rows, for example Line 1: Gigaset Communications, line 2: Please ring the bell!
 - Number: Destination number when you press the bell, in the example, the group number 199
 - DTMF code: 4-digit code to trigger a function
 - Incoming: Reject
 - Relay: On
 - Group ID: None

Zentralruf (Anzeigetexte)

Name	Nummer	DTMF-Code	Ankommend	Abgehend	Relais	Gruppen-ID
116 Gigaset Com.	199	1 ▼ 2 ▼ 3 ▼ 4 ▼	Abweisen ▼	Ansage An ▼	An ▼	Keine ▼
Herzlich Willkommen						
<input type="text"/>						

VoIP settings

- CODECs
 - Codec 1: PCMA
 - Codec 2: PCMU
 - Codec 2-6: None
- SIP settings
 - SIP Registration: [x] Yes
 - SIP Server: <Gigaset-IP>
 - SIP server port: 5060
 - SIP Domain: <Gigaset-IP>
 - SIP outbound proxy server: [x] No
 - Use DNS SRV: [x] No
 - SIP User ID: <SIP-Telefon-Name>
 - SIP authentication ID: <SIP-Telephone-Name>
 - SIP authentication PIN: <SIP-Telephone-Passwort>
 - Username: <SIP-Telephone-Name>

SIP Einstellungen

SIP Registrierung: Nein Ja

SIP Server: (IP oder URI)

SIP Server Port: (Standard 5060)

SIP Domain:

SIP Server als Outbound Proxy: Nein Ja

Benutze DNS SRV: Nein Ja

SIP Benutzer ID:

SIP Authentifizierung ID:

SIP Authentifizierung PIN:

Benutzername: (Optional, z.B. Max Mustermann)

- Advanced SIP Settings
 - Send DTMF: RFC2833
 - Support PRACK (RFC3262): [x] no
 - Please leave the other values at their default settings
- System
 - Syslog Server IP: <Gigaset-IP> (please use only in case of support)
 - SNTP Server: <Gigaset-IP>
 - Time zone: GMT +01:00
 - Clock adjust: [x] yes

Hardware settings

Please make the settings according to the manufacturer's instructions and the requirements on site.

Configuration of CP-CAM

Important Note:

Please follow carefully the instructions of the manufacturer's documentation for setup.

In combination with the Gigaset PBX, the CP-CAM must be operated with a fixed IP address - either by a fixed configuration in the device or via a static lease in the DHCP server.

Configuration actions

- Settings --> Camera
 - Mode: QVGA (320 x 240)
 - Number of frames per second (sensor): 15
 - Displayed images (video): Each 2nd

- If necessary change other settings to your requirements.

If a password protection for the interrogation of the video image is configured, following URL instead of the default one (mentioned above):

<Username> http://: @ <Password> <IP-address CP-CAM> / jpg / image.jpg

Manufacturer's documentation

- Manufacturer's documentation is available on the Baudisch website : <http://www.baudisch.de/downloads#anleitungen> (password: SIP-hightech)
- Manufacturers package to download: available [here!](#)

Sample Images

Sample images for demonstration purposes

Anzeige im Gigaset DE900 Telefon