

# LDAP Configuration - N510 IP PRO - SW version 199 or better

## LDAP configuration in Web Configurator

- Open web configurator in browser with IP address of N510 IP PRO
- Log in
- Go to *Settings* -> *Directories* -> *Corporate Directory* section

## Step-by-step guide

1. [LDAP server configuration with N510 IP PRO](#)
2. [LDAP entry's details configuration with N510 IP PRO](#)
3. [LDAP filters configuration with N510 IP PRO](#)

## Provisioning

[LDAP Provisioning Parameter - N510 IP PRO](#)