

FAQ SL800H / S700H / R700H - Reset

Introduction

The following reset options are available.

- Via the menu: **menu - settings - system - handset reset**
 - Changes language settings back to default
 - Melodies back to default
 - Handset is still registered to the DECT system
- Via the code: Enter menu: *#73738# (*#reset#)
 - Changes language settings back to default. In case a user changed the language and you can't find the menu in the new language anymore
 - Handset is still registered to the DECT system
- Factory reset: **menu - settings - system - erase handset**
 - All settings are set to the factory default settings
 - Handset DECT registration is also gone. New registration is needed

Feature	Menu - Handset reset	Via code	Menu - erase handset	Hotline reset	Automatic - Hotel mode	Via service menu
Call Divert	-	-	2*	-	N.A.	2*
Call waiting	-	-	2*	-	N.A.	2*
DND	-	-	2*	-	N.A.	2*
One-Touch Call	N.A.	N.A.	N.A.	N.A.	N.A.	N.A.
Call Lists	-	-	2*	-	•	2*
Audio settings	•	•	•	•	-	•
Calendar	•	•	•	•	N.A.	•
Timer	•	•	•	•	-	•
Alarm Clock	•	•	•	•	-	•
Missed alarms						
Contacts	-	-	•	•	N.A.	•
Screen saver	•	•	•	•	-	•
Large font	•	•	•	•	-	•
Colour Schemes	•	•	•	•	-	•
Display Backlight	•	•	•	•		•
Alerting Key	Not functional in this software					
Key illumination	•	•	•	•		•
Auto keypad lock	•	•	•	•		•
Language	•	•	•	•	-	•
DECT Registration	-	-	•	-	-	•
Bluetooth	1*	1*	•	1*	N.A.	•
Auto-Answer	-	-	•	•		•
Auto-accept call	-	-	•	-	N.A.	•
Area codes	-	-	•	•	N.A.	•
Country	•	•	•	•	N.A.	•
Emergency numbers	-	-	•	•	N.A.	•
Handset PIN	-	-	•	•	N.A.	•
Soft keys	•	•	•	•		•

1* = Bluetooth is disabled but list with devices is not removed

2* = This is a feature coming from the Base station, a handset reset does not remove a Base station function.