

FAQ Nx70 - AML supported handsets

Introduction

The following handsets can be used for AML, other handsets are **not** supported.

| AML feature | SL800H PRO | S700H PRO | R700H PRO | R650H PRO | S650H PRO | SL750H PRO | OpenStage M3 |
|---|------------|-----------|-----------|-----------|-----------|------------|--------------|
| Receive/show messages | • | • | • | • | • | • | • |
| Up to 2 message paragraphs | • | • | • | • | • | • | • |
| Message text: Align / Blinking / Bold / Underline | • | • | • | • | • | • | • |
| Message text color | • | • | • | - | - | - | - |
| Message icons: Advanced/Basic | */• | */• | */• | -/• | -/• | -/• | -/• |
| Colored icons | • | • | • | - | - | - | - |
| Message ringtones Advanced/Basic | */• | */• | */• | -/• | -/• | -/• | -/• |
| Reply message using softkeys | • | • | • | • | • | • | • |
| Message list | • | • | • | • | • | • | • |
| Message list icons | • | • | • | - | - | - | - |
| Override handset settings (DND/volume /vibration) | • | • | • | - | - | - | - |
| Message presentation timer | • | • | • | • | • | • | • |
| Message time to live | • | • | • | • | • | • | • |
| DECT Location | • | • | • | - | • | • | • |
| BT Location | • | • | • | - | - | - | - |
| Auto provisioning of the DECT handsets | • | • | • | - | - | - | - |
| Alarm call via feature key (Call based) | - | • | • | - | - | - | - |
| Man down / Fast motion / Pull cord / ... | - | - | - | - | - | - | • |