FAQ - Call limits / capacity per base station

Valid for:	~~N610~~	N670	N870	N870E	Embedded Integrator	Virtual Integrator

Valid for N670 / N870 / N870E.

The capacity of the device is based on the device role and the enabled codec.

- Small size system
- Medium size system
- Large / Enterprise system

How to switch from small to medium. FAQ - Switch from Small to Medium system