
FAQ - Virtual integrator with multiple N870 DECT Managers



Subscribers can

- Accept or initiate calls in all DECT cells with their handset (Roaming)
- Switch between the DECT cells during a call (Handover).
- A handover is only possible if cells are synchronised.



To allow inter-DECT-manager roaming, the regular load of handsets planned to be attached to one DECT manager would be lower (Approx. 80%)