

FAQ - RTP port

Valid for:	N610	N670	N870	N870E	Embedded Integrator	Virtual Integrator
------------	------	------	------	-------	---------------------	--------------------

Introduction

Changing the RTP port is today only possible via auto-provisioning.

Auto-provisioning

Parameter	Description
dm.local.RtpBasePort	Change the RTP port for DECT Manager local
dm.@.RtpBasePort	Change the RTP port for all DECT Managers
Example:	
<code><param name="dm.dm1.RtpBasePort" value="10000" /></code>	