

FAQ Maxwell - Dialling Plans

Introduction

You can define your own dialling plans in the **Dialling plans** area on the Web page: **Settings - Telephony - Dialling Plans**

You can specify the following Dialling Plans:

- You can define a connection for specific phone numbers, which is always to be used to dial these numbers.
- Define if the number is to be dialed with the area code.

Valid for Maxwell			
Basic	2	3	4

If dialling plans overlap, the one with the greatest concordance will apply.

Example:

There is a dialling plan for the number "02" and the one for number "023". If you dial "0231.." the second plan will apply, if you dial "0208..." the first plan will apply.

SETTINGS

STATUS

Network

Telephony

VoIP

Connections

Audio

Phone System

Call Settings

Call Divert

Do not Disturb

Dialling Plans

Voicemail

Dialling Plans

Phone number	Use area code	Connection	Comment	Active
85	☒	IP 1	Bocholt Office	☒

Phone number

Use area code

Connection

Comment

Active

☐

89162 Support

☒

+ Add

Example					
Area Code					
	Country	Germany			
	International	Prefix	00		
		Area Code	49		
	Local	Prefix	0		
		Area Code	287191		
Dialling Plans					
Phone number	Use area code	Connection	Comment	Number	Outgoing INVITE
89		IP 1	Bocholt Office	89999	004928719189999 via IP 1
86		IP 1	Bocholt Local	86000	86000 via IP 1
87		IP 2	Test	87000	87000 via IP 2
891		IP 2	Test2	89199	004928719189199 via IP 2

Auto provisioning

Parameter name	Description
Telephony.DiallingPlans.List.0-19.Number	
Telephony.DiallingPlans.List.0-19.UseAreaCode	0 = Disabled 1 = Enabled
Telephony.DiallingPlans.List.0-19.Connection	
Telephony.DiallingPlans.List.0-19.Comment	
Telephony.DiallingPlans.List.0-19.Active	0 = Disabled 1 = Enabled
Telephony.CallBarring.List.0-19.Number	
Telephony.CallBarring.List.0-19.Comment	
Telephony.CallBarring.List.0-19.Blocked	0 = Disabled 1 = Enabled
Example: <pre><param name="Telephony.DiallingPlans.List.0.Active" value="0"/> <param name="Telephony.DiallingPlans.List.0.Comment" value=""/> <param name="Telephony.DiallingPlans.List.0.Connection" value="0"/> <param name="Telephony.DiallingPlans.List.0.Number" value=""/> <param name="Telephony.DiallingPlans.List.0.UseAreaCode" value="0"/></pre>	