

FAQ Maxwell - Phone Web Server

Introduction

Open the web-interface of the Maxwell 3 / Basic and go to: **Settings - System - Phone Web Server**

Valid for Maxwell

Gigaset

4

⚙️ SETTINGS

≡ STATUS

Network

Telephony

Online Directories

Online Services

Desk Phone

Web Configurator

System

Phone Web Server

HTTP Server

HTTP Connection Type

HTTP port

HTTPS port

Automatic logout

HTTP + HTTPS

80

443

10 min.

Settings

Setting	Description
HTTP Connection Type	Select which HTTP connection for the Maxwell interface can be used HTTP HTTPS HTTP + HTTPS
HTTP port	Enter the number for the port to be used for communication via HTTP. The default setting is 80
HTTPS Port	Enter the number for the port to be used for communication via HTTPS. The default setting is 443
Automatic logout	Enter the time (minutes) after which an HTTP(S) connection should automatically end if no entries are made.

Auto provisioning

Parameter	Description
HTTP.ConnectionType	HTTP (Default) HTTPS HTTP_HTTPS
HTTP.Port	1 - 65535: 80 (Default)
HTTP.SecurePort	1 - 65535: 443 (Default)
WebUI.LogoutTimer	1 - 60: 10 (Default)