

# FAQ Maxwell - Desk Phone - Display

## Introduction

Open the web-interface of the Maxwell 3 / Basic and go to: **Settings - Desk Phone - Display**

Valid for Maxwell

Gigaset

4

SETTINGS

STATUS

Network

Telephony

Online Directories

Online Services

Desk Phone

Main Menu

Ringtones

Display

Display

LanguageEnglish

Standby Brightness3/10

Backlight7/10

Key ContrastDarkBright

Maxwell 4

Gigaset

SETTINGS

STATUS

Network

Telephony

Online Directories

Online Services

Desk Phone

Main Menu

Ringtones

Display

Display

LanguageEnglish

Colour Schemewhite on blue

Screensaver Brightness3/10

Standby Brightness3/10

Backlight7/10

Maxwell 3

Gigaset

SETTINGS

STATUS

Network

Telephony

Online Directories

Online Services

Desk Phone

Main Menu

Ringtones

Display

Display

LanguageEnglish

Screensaver Activation20 min.

ScreensaverAnalog clock

Screensaver Brightness3/10

Standby Brightness3/10




Backlight7/10

Maxwell 2



- Network >
- Telephony >
- Online Directories >
- Online Services >
- Desk Phone ▾
  - Main Menu
  - Ringtones
  - Display

## Display

- Language English ▾
- Screensaver Activation 20 min. ▾
- Colour Scheme white on black ▾
- Screensaver Brightness  3/10
- Standby Brightness  3/10
- Backlight  7/10
- Contrast  5/9

Maxwell Basic

## Settings

Setting	Description	Supported by Maxwell:	Provisioning parameter	Description
Language	The Maxwell display language	4 / 3 / 2 / B	PhoneUI.Settings.Language	en-us (Default) de-de fr-fr es-es it-it nl-nl tr-tr pt-pt el-gr da-dk sv-se no-no cs-cz pl-pl sl-sl ro-ro ru-ru
Standby brightness	The Maxwell 4 display brightness when you have not touched any key for some time.	4	PhoneUI.Settings.Backlight.Standby	1 - 10
Backlight	The Maxwell 4 Backlight	4	PhoneUI.Settings.Backlight	1 - 10
Key contrast	Function keys that can't be read when using a light background, select <b>Dark</b>	4	PhoneUI.Keys.FunctionKeys.Contrast	0 = Dark 1 = Bright
Screensaver Activation		2 / B	PhoneUI.Settings.ScreenSaverTimeout	0,10,20 (Default),30,40,50,60
Screensaver		2	PhoneUI.Settings.ScreenSaverSelection	0 = Analog clock 1 = Digital clock 2 = Pictures 3 = HTTP source Maxwell 2 only supports values 0 and 1
Color Scheme		3	PhoneUI.Settings.ColorScheme.Tree	0 - White on Black (see main screen then) 1 - White on Blue (see main screen then) 2 - White on Red (see main screen then) 3 - White on Green (see main screen then)  This parameter is ignored by Maxwell 2
Color Scheme		B	PhoneUI.Settings.ColorScheme.Basic	4 - White on Black (see main screen then) 5 - Black on White (see main screen then)
Screensaver Brightness		3 / 2 / B	PhoneUI.Settings.Backlight.Screensaver	1 - 10
Standby Brightness		3 / 2 / B	PhoneUI.Settings.Backlight.Standby	1 - 10
Backlight		3 / 2 / B	PhoneUI.Settings.Backlight	1 - 10
Contrast		B	PhoneUI.Settings.Contrast	1 - 10
			PhoneUI.Settings.BacklightTimeout	1 - 120: 5 (Default): Value is in minutes 0 = Disable the feature.