

FAQ Maxwell - Soft-keys

Introduction

The keys below the display are the Soft-keys, these keys can be configured with different features in IDLE mode.

- Maxwell B / 2 / 3 have 2 Soft-keys (Left and Right)
- Maxwell 4 has 4 Soft-keys

Valid for Maxwell			
Basic	2	3	4

Soft-Key	Feature
-1	No function
3	Quick Dial
5	SIP URI
8	Action URL
9	SIP INFO
10	FAC
11	Call Waiting
12	Local Directory
13	Ldap Directory
14	Xml Public
15	Xml Yellow
16	Xml Private
17	Redial
18	Select Line
22	XSI Personal Directory
23	XSI Group Common Directory
24	XSI Group Directory
25	XSI Enterprise Common Directory
26	XSI Enterprise Directory

Web interface

In the web-interface go to: **Settings - Desk Phone - Keys and LEDs**

Gigaset

SETTINGS **STATUS**

Network >

Telephony >

Online Directories >

Online Services >

Desk Phone ▾

 Main Menu

 Ringtones

 Display

 Pictures

 Message Notification

Keys and LEDs

 Expansion Module 1

 Events

 Local Phonebook

Programmable Keys

Key	Function
Directory	Corporate ▾
Messages	Default ▾
DND	Default ▾
Hold	Default ▾
Conference	Default ▾
Left	Redial ▾
Right	No function Quick Dial SIP URI Action URL SIP INFO FAC Call Waiting ▾

Quick Dial Keys

Key
Key 1

Auto provisioning

Parameter	Description
PhoneUI.Keys.SoftKeys.X.Type Maxwell B/ 2/ 3 / 4 X=0 Left SoftKey, X=1 Right Softkey Maxwell 4 X = 2 and X = 3 for the Soft keys in the middle	-1 = No function 3 = Quick Dial 5 = SIP URL 8 = Action URL 9 = SIP INFO 10 = FAC 11 = Call Waiting 12 = Local Directory 13 = Ldap Directory 14 = Xml Public 15 = Xml Yellow 16 = Xml Private 17 = Redial 18 = Select Line 22 = XSI Personal Directory 23 = XSI Group Common Directory 24 = XSI Group Directory 25 = XSI Enterprise Common Directory 26 = XSI Enterprise Directory
PhoneUI.Keys.SoftKeys.X.Action X = 0 - 3	Only Valid for: SIP INFO
PhoneUI.Keys.SoftKeys.X.Connection X = 0 - 3	Only Valid for: Quick Dial
PhoneUI.Keys.SoftKeys.X.DisableCode X = 0 - 3	Only Valid for: FAC
PhoneUI.Keys.SoftKeys.X.DisableName X = 0 - 3	Only Valid for: - SIP INFO - FAC
PhoneUI.Keys.SoftKeys.X.EnableCode X = 0 - 3	Only Valid for: FAC
PhoneUI.Keys.SoftKeys.X.EnableName X = 0 - 3	Only Valid for: - Quick Dial - SIP URI - Action URL - SIP INFO - FAC
PhoneUI.Keys.SoftKeys.X.PhoneNumber X = 0 - 3	Only Valid for: Quick Dial
PhoneUI.Keys.SoftKeys.X.URL X = 0 - 3	Only Valid for: - SIP URI - Action URL
SoftKeys.X.Active X = 0 - 3	0 = When SoftKey is FAC then change to disabled 1 = When SoftKey is FAC then change to enabled It will only change the key status, the device does not send the FAC.