

FAQ Maxwell - Web-UI Access

Introduction

To reach the Web-UI of Maxwell you need to open a Browser and type in the IP address of the phone.

The IP address of the phone can be found in the phone menu at **Settings/Info**

http://<ip-addr>

You will be automatically redirected to the Login page.

Valid for Maxwell

Basic

2


3

4

🔍 192.168.0.100/#/Login

To login to the Web-UI there are two different accounts available.

1. User Account
To login as a user you need to type in the password **user**
2. Admin Account
To login as a user you need to type in the password **admin**



The user account cannot be used for connection setting. It is designed to allow customization of the phone by the user without changing crucial setting like SIP account, online phonebooks etc.