

FAQ - Call limits / capacity per base station

Valid for:	N610	N670	N870	N870E	Embedded Integrator	Virtual Integrator
------------	-----------------	------	------	-------	---------------------	--------------------

Valid for N670 / N870 / N870E.

The capacity of the device is based on the device role and the enabled codec.

- [Small size system](#)
- [Medium size system](#)
- [Large / Enterprise system](#)

How to switch from small to medium. [FAQ - Switch from Small to Medium system](#)