

T300/T500 - Configuration of FXO port - parameter cidstart

There are two possibilities to influence the FXO port configuration regarding the "cidstart" parameter as follows:

1 Change parameter "cidstart" in conf file

Parameter can be changed in /etc/asterisk/chan_dahdi.conf:

```
cidstart = ring  
or  
cidstart = polarity
```

Finally please proceed with following commands:

1. stop asterisk: service asterisk stop
2. restart dahdi: service dahdi restart
3. start asterisk: service asterisk start

2 Change parameter "cidstart" in SQL database

With following SQL-Statement, the parameter "cidstart" can be changed.

```
update countrydefaultisdn set cidstart='polarity' where nationalcode like 'at';
```

```
cidstart = ring
```

```
select id, nationalcode, countrycode, cidstart from countrydefaultisdn where  
nationalcode like 'at';
```

id	nationalcode	countrycode	cldstart
2	at	43	ring

```
cidstart = polarity
```

```
select id, nationalcode, countrycode, cidstart from countrydefaultisdn where  
nationalcode like 'at';
```

id	nationalcode	countrycode	cldstart
2	at	43	polarity

- [1 Change parameter "cidstart" in conf file](#)
- [2 Change parameter "cidstart" in SQL database](#)