

# Maxwell 10 adb access

## Introduction

Maxwell 10 has an mini USB port behind the left cradle cover. You can connect Maxwell via USB to your PC to upload data but also to access the adb interface.

## Instruction

To get access to the adb interface, you have to activate USB debugging in the developer options.

Update drivers for “adb composite device” as well as “MTP” device drivers manually after connecting device to Windows PC.

Add “0x1e85” within file C:\Users\ininxxx\android\adb\_usb.ini or copy attached adb\_usb.ini file.

For linux please add “0x1e85” in /home/user/.android/adb\_usb.ini

## Driver

- [adb\\_usb.zip](#)
- [gigaset\\_usb\\_drvier\\_14032014.7z](#)

- [Introduction](#)
- [Instruction](#)
- [Driver](#)