DE700/900 - Doorintercom (video) / Camera as Screensaver

1.0 Introduction

Doorintercom systems with video or Camera's that generate JPG pictures (IP security camera) can be used as screensaver on the Gigaset DE900/700 devices. In Idle mode after 15 seconds, the devices can show the jpg picture of the camera, it will be refreshed every xx seconds.

1.1 Configure WEB-Camera in DE device




First you need to configure the Webcamera in the DE900/700 devices.

Open the web-interface of the DE900/700, go to: Settings - Services - IP Info Services - Webcam

- 1. Name of webcam: Enter the name of the Camera
- IP address of webcam (URL): The URL to the Camera picture: Example: http://192.168.178.69 /video.jpg


Press Add and then Save to store the settings.



On the same web-interface page, set the options:

- Activate Info Services: Yes
- Webcam: Select the web-camera you would like to show.

1.2 Set info service as screensaver.



Go to: Settings - Display

• Screensaver: Select "Info Service"



- 1.0 Introduction
- 1.1 Configure WEB-Camera in DE device
- 1.2 Set info service as screensaver.