

FAQ Maxwell - Phone overview Maxwell 3

Introduction

Key	Description
1	Display keys Activate display functions
2	Volume key Depending on the operating mode: Adjust the volume of the speaker, receiver, headset or ringtone
3	* Key Enable/disable ringtone
4	# Key # Key
5	Status-LED Status for incoming and active calls. Blinking: Incoming call On: Active call
6	Function keys Programmable keys (Not available in Maxwell Basic)
7	Navigation key Scroll through lists and enter (IDLE mode): Open Redial list
8	Do Not Disturb Do Not Disturb (DND) function
9	Message key Open message lists
10	Consultation key Initiate/end consultation call
11	End call/back key Go back one menu level (press briefly); return to idle status (press and hold)
12	Conference key Initiate conference call
13	Speaker key Activate/deactivate speaker
14	Headset key Make call via wired headset
15	Mute key Activate/deactivate microphone (mute)
16	Microphone Hands-free microphone



Maxwell 3 phone with numbered callouts 1-16 pointing to various features.

- 1: Display keys
- 2: Volume key
- 3: * Key
- 4: # Key
- 5: Status-LED
- 6: Function keys
- 7: Navigation key
- 8: Do Not Disturb
- 9: Message key
- 10: Consultation key
- 11: End call/back key
- 12: Conference key
- 13: Speaker key
- 14: Headset key
- 15: Mute key
- 16: Microphone