Firmware DX800A

Online update:

The firmware is online available.

You can easily initiate the update by three steps:

Prerequisite: The phone is connected to the Internet.

Via the Handset:

- 1. Menu » Settings » System » Update Firmware
- 2. Enter base station system PIN (default setting: 0000)
- 3. Press the display key "Yes" to start the download

If your firmware is already up to date, the handset will inform you. No action is needed then.


Via the webpage:

1. Settings » Management » Firmware update

Manual update:

Via the webpage:

- 1. Settings » Management » Firmware update
- 2. Enter the URL for the new firmware in the User defined firmware file: field
- 3. Click on the button: Update firmware







40
Ã.
Software version 173
Download
do:
Q.
Software version 158
Danieland
Download
N.
100
1
Software version 131
Download
Download