
FAQ - LED

Valid for:	N610	N670	N870	N870E	Embedded Integrator	~~Virtual Integrator~~


Valid for N610 / N670 / N870 / N870E.

Depending on the device role the LEDs on the front side show different operational states. The LEDs can have three different colours (red, blue, green) or can be off.


DECT manager and base stations




Base station operational states



DECT manager (without DECT)



DECT manager (with DECT)



Disabled LED's via auto-provisioning

Via auto-provisioning you can disable the LED's on the devices.

Parameter	Description
DmGlobal.0.bLedSignallingActive	Possibility to turn the LED's on the base Off or On. 0 = LED's off 1 = LED's on
Example: <param name="DmGlobal.0.bLedSignallingActive" value="1"/>	

Disabled LED's via the web-interface

From software 2.36 or higher it is possible to disable the LED's also via the web-interface.

In the web-interface go to: **Base stations - Administration**

