

# FAQ Maxwell - Quick Dial

Introduction

With Quick Dial, you can assign a number to the function key. When you press the Function key, the number will be dialed.

From software 2.16.6 or higher we implemented additional functionality.

Function key web-interface config example:

Valid for Maxwell

Basic234

4: TestQuick Dial85163\$P3\$dtmf1\$P...☐

FunctionQuick Dial

ConnectionGigaset

Target number85163\$P3\$dtmf1\$P15\$hu

Display NameTest

LED colour☒ Red☐ Yellow☐ Green☐ Default

Function	Description
A Quick Dial key always starts with a number	When the Quick Dial key is pressed, the number is dialed.
\$wc	Wait Connect: Wait until SIP connect is received
\$p5	Pause: Wait for .. seconds. In this example 5 seconds
\$dtmf1234	DTMF: Send DTMF tone. In this example 1234
\$hu	Hang up: Hang up, send BYE
Example: 85163\$P3\$dtmf1\$P15\$hu	Dial 85163, wait for 3 seconds, send DTMF tone "1", wait for 15 seconds and hang-up

Maximum characters allowed is 254

Maximum duration for execution is 180 seconds.