

# tftp provisioning

## Introduction

Maxwell 2 / 3 and Basic, from software 2.19 or higher also supports the tftp protocol for provisioning.

For this you need to change the provisioning URL from http://... to tftp://...