

Broadsoft step by step

Broadsoft Feature	N510	N720	N870/N670/N610	Maxwell 10	Maxwell 2/3/B
	 N510 IP	 N720 IP	 N870 IP/ N670 IP	 Maxwell 10	 Maxwell 3
Software version Gigaset	238	105	2.5.0	2.2.128	2.11.8
Advised software	245 • Phonebooks • Longer SIP Credentials	111 • Phonebooks	2.54.0 • Feature sync • Phonebook lookup • Conference 3pty* • N-way conference • N610 is supported		2.22.7 • Session Timer • Provisioning • Feature sync • XSI • BLF • Call Logs • ACD • Phone-books • Remote Office • Flex Seating
Broadworks software version	Rel. 21.0 / 21.sp1	Rel. 22	Rel. 22	Rel. 21.0 / 21.sp1	Rel. 22
Validation date	September 2016	May 2017	2018	February 2017	April 2017
Broadsoft official validation (Interop)	Yes	Yes	Yes	Yes	Yes
Device Management (Auto provisioning)	Yes	Yes	Yes	Yes	Yes
Broadsoft Partner Configuration Guide	Yes	Yes	Yes	Yes	Yes
Broadsoft CPE kit	Yes	Yes	Yes	Yes	Yes
Broadsoft test results	Yes	Yes	Yes	Yes	Yes
Feature sync			(FSK)	(XSI)	(FKS)
Do Not Disturb (DND)	-	-	Yes	Yes	Yes
Call forward always	-	-	Yes	Yes	Yes
Call forward busy	-	-	Yes	Yes	Yes
Call forward no answer	-	-	Yes	Yes	Yes
Call Center ACD	-	-	-	Yes	Yes
Phonebooks	(XSI)		(XSI)	(XSI)	(XSI)
Enterprise	Yes	Yes	Yes	-	Yes
Enterprise Common	Yes	Yes	Yes	-	Yes
Group	Yes	Yes	Yes	Yes	Yes
Group Common	Yes	Yes	Yes	Yes	Yes
Personal	Yes	Yes	Yes	Yes	Yes
HTTP / HTTPS	Yes/Yes	Yes/Yes	Yes/Yes		Yes
Call Lists				(XSI)	(XSI)
Enhanced Broadsoft Call Logs	-	-	Yes	Yes	Yes
Basic Broadsoft Call logs	-	-		Yes	Yes
All	Yes *	Yes *	Yes	Yes	Yes
Accepted	Yes *	Yes *	Yes	Yes	Yes
Missed	Yes *	Yes *	Yes	Yes	Yes
Placed	Yes *	Yes *	Yes	Yes	Yes

Busy Lamp Field (BLF)					
Manual configuration	-	-	-	Yes	Yes
Automatic configuration	-	-	-	-	Yes
Auto provisioning					
HTTP auto provisioning	Yes	Yes	Yes	Yes	Yes
HTTPS auto provisioning (Client Certificate)	Yes	Yes	Yes		Yes
HTTP Digest via Redirect	Yes	Yes	Yes		Yes
HTTP Digest via MMI	-	-	-		Yes
Others					
Remote Office	-	-	-	-	Yes
Flexseating	-	-	-	-	Yes
N-way conference	-	-	Yes	-	-
Manuals					
	N510 Quick start guide	N720 Quick start guide			Maxwell 3 Quick start guide

* = Local feature of the device, not synchronized with Broadsoft platform.