

# FAQ N510 Client certificates

## Introduction

From software 245 we have implemented the usage of client certificates when using secure provisioning.

To use this feature, it must be enabled first.

For this we created a patch that you can install via the restore function in the device. (**Settings – management – Save and Restore**)

After the restore, the device will:

- Reboot
- After boot, the device generates the Client certificate in the background
- This takes about 5 minutes
- Then automatic without an extra reboot, the client certificate can be used.



You can not see if the certificate generation is ready, just wait for 5 minutes.

It will not change or delete any other existing parameters, only the client certificate will be enabled.

Download