

FAQ N720 Maxwell C support

Introduction

The [Maxwell C](#) is fully supported behind the N720 from [Software 111](#) or higher. If the software is older then it will operate in GAP modes with limited functionality.

[Download](#)

Firmware update

1. Upgrade your N720 to [Software 111](#) or higher.
2. After the upgrade, the Maxwell C will be fully supported.

Patch

If you would like to use the Maxwell C with older software, you can download this patch and install this on your N720.

1. Download the Patch file and put this on your PC.
2. Open the web-interface of the N720, go to: Settings - Management - Save & Restore.
3. Restore this Patch file.
4. Device will reboot.
5. After the reboot the Maxwell C will be fully supported.