

# FAQ - Auto provisioning: Parameters

Valid for: N610 N670 N870 N870E Embedded Integrator Virtual Integrator

| Web-interface: Settings - Network - IP                    |                                                                               |                                                                                                                                                                                    |
|-----------------------------------------------------------|-------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                           | Web-interface Language                                                        |                                                                                                                                                                                    |
| WebUI.1.Language                                          | cs-cz,de-de,el-gr,en-bt,es-es,fr-fr,it-it,nl-nl,pt-pt,ru-ru,sk-sk,tr-tr,pl-pl | <b>Language:</b> Current supported web-interface language is English, German, Russian, Czech, Spanish, French, Italian, Netherlands, Portuguese, Slovenian, Turkey, Greece, Polish |
|                                                           | Device name                                                                   |                                                                                                                                                                                    |
| Not via provisioning                                      |                                                                               | <b>Device name in the network:</b> Label for the device. It is used to identify the device in network communication.                                                               |
|                                                           | Address Assignment                                                            |                                                                                                                                                                                    |
| Not via provisioning                                      |                                                                               | <b>Network type:</b> IPv4 / IPv6 (planned)                                                                                                                                         |
| Supported see <a href="#">Wiki</a> for details            | dhcp - static                                                                 | <b>IP address type:</b> Dynamic / Static                                                                                                                                           |
| Supported see <a href="#">Wiki</a> for details            |                                                                               | <b>IP address:</b>                                                                                                                                                                 |
| Supported see <a href="#">Wiki</a> for details            |                                                                               | <b>Subnet mask:</b>                                                                                                                                                                |
| Supported see <a href="#">Wiki</a> for details            |                                                                               | <b>Standard gateway:</b>                                                                                                                                                           |
| Supported see <a href="#">Wiki</a> for details            |                                                                               | <b>Preferred DNS:</b>                                                                                                                                                              |
| Supported see <a href="#">Wiki</a> for details            |                                                                               | <b>Alternate DNS:</b>                                                                                                                                                              |
| Web-interface: Settings - Network - LAN                   |                                                                               |                                                                                                                                                                                    |
|                                                           | VLAN                                                                          |                                                                                                                                                                                    |
| Supported see <a href="#">Wiki</a> for details            | vlan - eth0                                                                   | <b>VLAN tagging:</b>                                                                                                                                                               |
| Supported see <a href="#">Wiki</a> for details            | 0 - 4094                                                                      | <b>VLAN identifier:</b>                                                                                                                                                            |
| Supported see <a href="#">Wiki</a> for details            | 0 - 7                                                                         | <b>VLAN priority:</b>                                                                                                                                                              |
| Web-interface: Settings - Base stations - Administration  |                                                                               |                                                                                                                                                                                    |
| ConfirmedBaseStations.<mac>.name                          |                                                                               | <b>Name / Location</b> This name should make it easier to assign the base station within the logical and spatial structure of the DECT network                                     |
| ConfirmedBaseStations.<mac>.ucTxPower                     | 1                                                                             | 0 = Normal power output (Default)<br>1= Reduce TX power by 8dB for external antenna operation                                                                                      |
| ConfirmedBaseStations.<mac>.bActivateCell                 | 1                                                                             | 0 = Base station deactivated<br>1 = Activated base station (Default)                                                                                                               |
| Web-interface: Settings - Base stations - Synchronization |                                                                               |                                                                                                                                                                                    |
| ConfirmedBaseStations.<mac>.ucCluster                     | 1 - 10                                                                        | Select the cluster to which the base should be assigned to from the option menu.                                                                                                   |
| ConfirmedBaseStations.<mac>.ucSyncLevel                   | 0 - 15                                                                        | Select the synchronization level for the base station.                                                                                                                             |
| ConfirmedBaseStations.<mac>.bSyncLanMaster                | 0 - 1                                                                         | 0 = Off (Default)<br>1 = LAN Master                                                                                                                                                |

| Web-interface: Settings - Provider or PBX profiles |                                                                         |                                                                                                                                                                                        |
|----------------------------------------------------|-------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| VoIP Provider                                      |                                                                         |                                                                                                                                                                                        |
| SipProvider.<0-19>.Name                            |                                                                         | <b>Connection name or number:</b> Name for the provider or PBX profile. This name is shown in the Provider/PBX list                                                                    |
| Phone system                                       |                                                                         |                                                                                                                                                                                        |
| SipProvider.<0-19>.PhoneSystem                     | 0 = Automatic<br>1 = Standard<br>6 = Broadsoft<br>10 = Swyx<br>11 = 3CX | <b>System:</b> Select the type of PBX you use for VoIP provisioning from the option menu.                                                                                              |
| General data of your service provider              |                                                                         |                                                                                                                                                                                        |
| SipProvider.<0-19>.Domain                          |                                                                         | <b>Domain:</b> Domain part of the user address (SIP URI)                                                                                                                               |
| SipProvider.<0-19>.ProxyServerAddress              | IP address/ DNS name                                                    | <b>Proxy server address:</b> The SIP proxy is your VoIP provider's gateway server and the first SIP server, where the device should send SIP requests and expects to receive requests  |
| SipProvider.<0-19>.ProxyServerPort                 | 1 - 65535                                                               | <b>Proxy server port (Default 5060):</b> Enter the port number of the first SIP server, where the device should send SIP requests and expects to receive requests.                     |
| SipProvider.<0-19>.RegServerAddress                | IP address/ DNS name                                                    | <b>Registration server:</b> The registration server assigns the public IP address/port number that was used by the phone on registration to your SIP address (username@domain)         |
| SipProvider.<0-19>.RegServerPort                   | 1 - 65535                                                               | <b>Registration server port (Default 5060):</b> Enter the communication port used on the registrar.                                                                                    |
| SipProvider.<0-19>.RegServerRefreshTimer           | 1 - 5 digits                                                            | <b>Registration refresh time (Default 180):</b> Enter the time intervals (in seconds) at which the phone should repeat the registration with the VoIP server (SIP proxy)               |
| SipProvider.<0-19>.TransportProtocol               | 1 = UDP<br>2 = TCP<br>3 = TLS                                           | <b>Transport protocol:</b>                                                                                                                                                             |
| SipProvider.<0-19>.UseSIPS                         | 0 = SIPS disabled (Default)<br>1 = SIPS enabled                         | <b>Use SIP Security (SIPS):</b>                                                                                                                                                        |
| SipProvider.<0-19>.SRTP_Enabled                    | 0 = SRTP disabled (Default)<br>1 = SRTP enabled                         | <b>Secure Real Time Protocol:</b> Security (RTP) is activated for voice connections.                                                                                                   |
| SipProvider.<0-19>.AcceptNonSRTPCalls              | 0 = Do not accept non-SRTP calls<br>1 = Accepts non-SRTP calls          | <b>Accept non-SRTP calls:</b> Insecure calls are accepted even when SRTP is activated.                                                                                                 |
| SipProvider.<0-19>.WithDeregOnHsNotReachable       | 0 = No<br>1 = Yes                                                       | <b>Deregister detached HS</b>                                                                                                                                                          |
| Redundancy                                         |                                                                         |                                                                                                                                                                                        |
| SipProvider.<0-19>.DnsQuery                        | 0 = A<br>1 = SRV + A<br>2 = NAPTR (NAPTR + SRV + A)                     | <b>Redundancy - DNS query:</b> VoIP providers provide SIP server redundancy for load balancing and service reliability. SIP servers can be identified by DNS using different queries:. |
| Failover Server                                    |                                                                         |                                                                                                                                                                                        |
| SipProvider.<0-19>.FailoverServerEnabled           | 0 = Off<br>1 = On                                                       | <b>Failover Server:</b>                                                                                                                                                                |
| SipProvider.<0-19>.FailoverServerAddress           | IP address/ DNS name                                                    | <b>Registration server:</b> Enter the IP address or the (fully qualified) DNS name of the failover registration server.                                                                |
| SipProvider.<0-19>.FailoverServerPort              | 1- 65535                                                                | <b>Registration port (Default 5060):</b> The communication port used on the failover registrar.                                                                                        |
| Network data of your service provider              |                                                                         |                                                                                                                                                                                        |
| SipProvider.<0-19>.OutboundProxyMode               | 0 = Always<br>2 = Never                                                 | <b>Outbound proxy mode:</b>                                                                                                                                                            |

|                                         |                                                                                                                                                                                             |                                                                                                                                                                        |
|-----------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SipProvider.<0-19>.OutboundProxyAddress | IP address/ DNS name                                                                                                                                                                        | <b>Outbound server address:</b>                                                                                                                                        |
| SipProvider.<0-19>.OutboundProxyPort    | 1 - 65535                                                                                                                                                                                   | <b>Outbound proxy port (Default 5060)</b>                                                                                                                              |
| SipProvider.<0-19>.MWISubscription      | 0 = Do not send SIP Subscribe for MWI<br>1 = Send SIP Subscribe for MWI                                                                                                                     | <b>SIP SUBSCRIBE for Net-AM MWI:</b> When activated a subscription is established for the purpose of receiving notifications about new messages on the network mailbox |
| DTMF over VoIP Connections              |                                                                                                                                                                                             |                                                                                                                                                                        |
| SipProvider.<0-19>.DTMFTransmission     | 1 = Audio<br>2 = RFC 2833<br>3 = Audio + RFC 2833<br>4 = SIP INFO<br>5 = Audio + SIP INFO<br>6 = RFC 2833 + SIP INFO<br>7 = Audio + RFC 2833 + SIP INFO<br>129 = Automatic DTMF Negotiation | <b>Send settings of DTMF transmission</b>                                                                                                                              |
| Connection Ringtone                     |                                                                                                                                                                                             |                                                                                                                                                                        |
| SipRingtones.<0-19>.RingToneName0       | Internal Calls                                                                                                                                                                              | Internal calls name ( <b>This can not be changed</b> )                                                                                                                 |
| SipRingtones.<0-19>.RingInfo0           | info=alert-internal                                                                                                                                                                         | Internal calls Alert-Info pattern                                                                                                                                      |
| SipRingtones.<0-19>.RingToneName1       | External Calls                                                                                                                                                                              | External calls name                                                                                                                                                    |
| SipRingtones.<0-19>.RingInfo1           | info=alert-external                                                                                                                                                                         | External calls Alert-Info pattern                                                                                                                                      |
| SipRingtones.<0-19>.RingToneName2       | Group Calls                                                                                                                                                                                 | Group calls name                                                                                                                                                       |
| SipRingtones.<0-19>.RingInfo2           | info=alert-group                                                                                                                                                                            | Group calls Alert-Info pattern                                                                                                                                         |
| SipRingtones.<0-19>.RingToneName3       | Door station                                                                                                                                                                                | Door station name                                                                                                                                                      |
| SipRingtones.<0-19>.RingInfo3           | info=alert-door                                                                                                                                                                             | Door stations Alert-Info pattern                                                                                                                                       |
| SipRingtones.<0-19>.RingToneName4       | Emergency                                                                                                                                                                                   | Emergency name                                                                                                                                                         |
| SipRingtones.<0-19>.RingInfo4           | info=alert-emergency                                                                                                                                                                        | Emergency Alert-Info pattern                                                                                                                                           |
| SipRingtones.<0-19>.RingToneName5       | Optional                                                                                                                                                                                    | Optional Name                                                                                                                                                          |
| SipRingtones.<0-19>.RingInfo5           | By default this is empty                                                                                                                                                                    | Optional Alert-Info pattern                                                                                                                                            |
| DmGlobal.0.SupportSipRingtones          | 0 = Disabled<br>1 = Enabled (Default)                                                                                                                                                       | Disable Distinctive ring (Option is not available in the web-interface)                                                                                                |
| SipRingtones.0.DefaultTone              | 0 = Internal<br>1 = External (Default)<br>2 = Group<br>3 = Door<br>4 = Emergency<br>5 = Optional                                                                                            | The tone played when the Alert info header is not recognized. By default the External ringtone is played. (Option is not available in the web-interface)               |
| Settings for Codecs                     |                                                                                                                                                                                             |                                                                                                                                                                        |

|                                                                  |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
|------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SipProvider.<0-19>.ActiveCodecs                                  | 0 = g711u<br>8 = g711a<br>9 = g722<br>18 = g729<br><br>Example: 18,9,8,0                                                          | <b>Active codecs:</b>                                                                                                                                                                                                                                                                                                              |
| SipProvider.<0-19>.RTPptime                                      | 10, 20, 30                                                                                                                        | <b>RTP Packetisation Time (ptime):</b> Length of time in milliseconds (10, 20 (Default), 30) represented by the audio data in one packet.                                                                                                                                                                                          |
| SipProvider.<0-19>.HoldType                                      | 0 = Inactive<br>1 = Sendonly (Default)                                                                                            | <b>Signalling options for 'Hold' in Session Description Protocol (SDP):</b> Call hold means that a user request to put an active call on hold. The holding part sends a reINVITE request to the held client with an SDP offer (Session Description Protocol). This SDP offer contains the attribute line a=inactive or a=sendonly. |
| SipProvider.<0-19>.CT_HoldTT_Attened                             | 0 = No<br>1 = Yes                                                                                                                 | <b>Hold towards Transfer-Target:</b> The device enables call transfer after consultation or without consultation. Define, whether a consultation call with transfer target is put on-hold prior to the execution of the call transfer (Yes) or not (No)                                                                            |
| Display of Caller Information                                    |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
| SipProvider.<0-19>.CLIPSource                                    | 0 = FROM<br>1 = PPI+FROM<br>2 = PAI (sip)<br>+PPI+FROM (Default)<br>3 = PAI (tel)<br>+PPI+FROM<br>4 = PAI (tel)<br>+FROM+PAI(sip) | <b>Calling Party (User Part):</b> From the option menu select which information is allowed to be transferred to the receiving part within the SIP header. Which information is actually transferred is determined by the provider.                                                                                                 |
| SipProvider.<0-19>.EnableHistoryHeaders                          | 0 = Disable<br>1 = Enable (Default)                                                                                               | <b>Redirected incoming call from other user:</b> The SIP Diversion Header can be inserted in the SIP INVITE when you receive a redirected incoming call from another user. Via this parameter you are able to show or hide the extra information.                                                                                  |
| Service Codes                                                    |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
| SipProvider.<0-19>.ServiceCode_CC_On                             |                                                                                                                                   | <b>Call Completion on (CCBS, CCNR):</b>                                                                                                                                                                                                                                                                                            |
| SipProvider.<0-19>.ServiceCode_CC_Off                            |                                                                                                                                   | <b>Call Completion off (CCBS, CCNR):</b>                                                                                                                                                                                                                                                                                           |
| CSTA                                                             |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
| SipProvider.<0-19>.CSTA_IsActive                                 | 0 = No<br>1 = Yes                                                                                                                 | <b>Active:</b> Computer Supported Telecommunications Applications is a standard for the interaction between a computer and a PBX, independently from the manufacturer. If your PBX provides CSTA applications to be used by the registered handsets you have to activate the standard here.                                        |
| SipProvider.<0-19>.CSTA_IsExternal                               | 0 = No<br>1 = Yes                                                                                                                 | <b>External:</b>                                                                                                                                                                                                                                                                                                                   |
| SipProvider.<0-19>.CSTA_Address                                  |                                                                                                                                   | <b>Address:</b> CSTA server address                                                                                                                                                                                                                                                                                                |
| SipProvider.<0-19>.CSTA_Port                                     |                                                                                                                                   | <b>Port:</b> CSTA port, default 5060                                                                                                                                                                                                                                                                                               |
| SipProvider.<0-19>.CSTA_RegServerRefreshTimer                    | 600                                                                                                                               | CSTA Refresh timer, default 600 seconds                                                                                                                                                                                                                                                                                            |
| SipProvider.<0-19>.CSTA_DnsQuery                                 | 0 = A<br>1 = SRV +A                                                                                                               | <b>DNS query:</b>                                                                                                                                                                                                                                                                                                                  |
| SipProvider.<0-19>.CSTA_TransportProtocol                        | 1 = UDP<br>2 = TCP<br>3 = TLS                                                                                                     | CSTA protocol                                                                                                                                                                                                                                                                                                                      |
| <b>Web-interface: Settings - Mobile devices</b>                  |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
| Global Settings                                                  |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
| DmGlobal.0.HSIdleDisplay                                         | 0 = Username<br>1 = Display name                                                                                                  | <b>Displayed name in idle display:</b>                                                                                                                                                                                                                                                                                             |
| <b>Web-interface: Settings - Mobile devices - Administration</b> |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |
| Mobile device                                                    |                                                                                                                                   |                                                                                                                                                                                                                                                                                                                                    |

|                                    |                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                        |
|------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| hs.<ipui>.Ipui                     |                                                                                                                                     | <b>IPUI:</b> (International Portable User Identity) Unique identifier of a handset within the DECT network. If you edit an existing handset registration entry, the IPUI is shown and cannot be changed.                                                                                                                               |
| hs.<ipui>.RegStatus                | ToReg = "To Register", add new Handset<br>ToDeReg = "To DeRegister", delete existing HS<br>NotReg = "Not Registered", default value | <b>RegStatus:</b> DECT registration status of the handset entry.                                                                                                                                                                                                                                                                       |
| hs.<ipui>.DECT_AC                  | min. 1, max. 4 digits                                                                                                               | <b>Authentication Code (PIN):</b> This PIN must be used on the handset to register with the DECT network.                                                                                                                                                                                                                              |
| Personal provider data             |                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                        |
| SipAccount.<ipui>.AuthName         | Max. 74 characters                                                                                                                  | <b>SIP Authentication name:</b> Specify the SIP authentication (HTTP digest) name. The Authentication name acts as access ID when registering with the SIP proxy/registrar server. It is usually identical to the phone number for the VoIP account.                                                                                   |
| SipAccount.<ipui>.AuthPassword     | Max. 74 characters                                                                                                                  | <b>SIP Authentication password:</b> Enter the password for SIP authentication (HTTP digest). The phone needs the password when registering with the SIP proxy/registrar server.                                                                                                                                                        |
| SipAccount.<ipui>.UserName         | Max. 74 characters                                                                                                                  | <b>SIP Username:</b> Enter the caller ID for the VoIP provider account. It is usually identical to the phone number for the VoIP account.                                                                                                                                                                                              |
| SipAccount.<ipui>.DisplayName      | Max. 74 characters                                                                                                                  | <b>SIP Display name:</b>                                                                                                                                                                                                                                                                                                               |
| SipAccount.<ipui>.ProviderId       | 0 - 19                                                                                                                              | <b>VoIP provider:</b>                                                                                                                                                                                                                                                                                                                  |
| Online directories                 |                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                        |
| hs.<ipui>.DirectAccessDir          | <a href="#">See this wiki page.</a>                                                                                                 | <b>Directory for direct access:</b> The user can press and hold the directory key (bottom of the control key) to open either the list of online directories or the local directory of the handset. Choose which directory is called up with the directory key.                                                                         |
| hs.<ipui>.IntKeyDir                | <a href="#">See this wiki page.</a>                                                                                                 | <b>Corporate directory for INT key:</b> If a corporate directory is available and configured the user can open it by pressing the INT key (left on the handset's control key). Choose from the list which corporate directory is opened with the INT key.                                                                              |
| hs.<ipui>.AutoLookupDir            | <a href="#">See this wiki page.</a>                                                                                                 | <b>Automatic look-up:</b> Select an online directory from the list for Automatic look-up or deactivate this option. When there is an incoming call, the caller's name is read from this directory and shown in the display (the availability of this function depends on the online directory provider).                               |
| LDAP authentication                |                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                        |
| hs.<ipui>.LDAPId                   | 255 = None<br>0 = LDAP 1<br>1 = LDAP 2<br>...                                                                                       | <b>Selected LDAP book:</b> Select the LDAP directory to be provided on the handset from the option menu.                                                                                                                                                                                                                               |
| hs.<ipui>.LDAPShowProviders        | 0 = No<br>1 = Yes                                                                                                                   | <b>Show other LDAP servers:</b> Select Yes if directories of other LDAP servers should be allowed to be shown.                                                                                                                                                                                                                         |
| hs.<ipui>.LDAPAuthType             | 0 = Global<br>1 = User<br>2 = SIP                                                                                                   | <b>LDAP authorization type:</b> Select how the user authentication should be performed:<br><br>Global: Credentials are set for all handsets during the LDAP directory set-up.<br>User: Individual credentials are used.<br>SIP: The credentials for the user's SIP account are used (Authentication name and Authentication password). |
| hs.<ipui>.LDAPUsername             | Max. 254 characters                                                                                                                 | <b>LDAP Username:</b> Enter the user name for individually accessing the LDAP directory.                                                                                                                                                                                                                                               |
| hs.<ipui>.LDAPPassword             | Max. 254 characters                                                                                                                 | <b>LDAP Password:</b> Enter the password for individually accessing the LDAP directory.                                                                                                                                                                                                                                                |
| Network mailbox configuration      |                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                        |
| SipAccount.<ipui>.VoiceMailMailbox |                                                                                                                                     | <b>Call number or SIP name (URI):</b> Enter the Call number or SIP name (URI) for the network mailbox.                                                                                                                                                                                                                                 |

|                                                                       |                                                                                                            |                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SipAccount.<ipui>.VoiceMailActive                                     | 0 = Disabled<br>1 = Enabled                                                                                | <b>Activate Voicemail box</b>                                                                                                                                                                                                                            |
| Group pick-up                                                         |                                                                                                            |                                                                                                                                                                                                                                                          |
| SipAccount.<ipui>.OpenScapeGroupPickupAddress                         |                                                                                                            | <b>Call number or SIP name (URI):</b> Enter the Call number or SIP name (URI) of the pick-up group.                                                                                                                                                      |
| SipAccount.<ipui>.OpenScapeGroupPickupActive                          | 0 = Disabled<br>1 = Enabled                                                                                | <b>Activate group pick-up</b>                                                                                                                                                                                                                            |
| DmGlobal.0.CallPickUpAlertCall                                        | 0 = Disable:<br>Notification tone is played<br><br>1 = Enable:<br>Notification tone and Ringtone is played | Not available in the web-interface                                                                                                                                                                                                                       |
| Call manager                                                          |                                                                                                            |                                                                                                                                                                                                                                                          |
| hs.<ipui>.CallManagerCallsVia                                         | No<br>Headset<br>Handsfree                                                                                 | <b>Accept calls directly via Call Manager:</b> From the option menu select whether calls that are transferred via the PBX call manager are to be accepted directly via Headset, via Handsfree or not at all (No).                                        |
| Missed calls and alarms                                               |                                                                                                            |                                                                                                                                                                                                                                                          |
| hs.<ipui>.SaveMissedCalls                                             | 0 = No<br>1 = Yes                                                                                          | <b>Missed/accepted calls count:</b> Select Yes/No, to activate/deactivate the call counter for missed and accepted calls. The information is displayed in the handset's call lists, missed calls are also shown on the handset's idle display.           |
| hs.<ipui>.SaveAcceptedCalls                                           | 0 = No<br>1 = Yes                                                                                          | <b>Accepted calls count</b>                                                                                                                                                                                                                              |
| hs.<ipui>.ShowMissedCalls                                             | 0 = No<br>1 = Yes                                                                                          | <b>Flashing LED (MWI) for missed calls:</b> Select Yes/No, to activate/deactivate the MWI LED on the handset's message key for missed calls.                                                                                                             |
| hs.<ipui>.ShowMissedAlarms                                            | 0 = No<br>1 = Yes                                                                                          | <b>Flashing LED (MWI) for missed alarms:</b> Select Yes/No, to activate/deactivate the MWI LED on the handset's message key for missed alarms.                                                                                                           |
| hs.<ipui>.ShowMissedNetAM                                             | 0 = No<br>1 = Yes                                                                                          | <b>Flashing LED (MWI) for network mailbox:</b> Select Yes/No, to activate/deactivate the MWI LED on the handset's message key for new messages on the network mailbox.                                                                                   |
| CallWaiting                                                           |                                                                                                            |                                                                                                                                                                                                                                                          |
| SipAccount.<ipui>.CallWaiting                                         | 0 = No<br>1 = Yes                                                                                          | Enable or disable call waiting, setting is not available in the web-interface.                                                                                                                                                                           |
| CSTA                                                                  |                                                                                                            |                                                                                                                                                                                                                                                          |
| SipAccount.<ipui>.CSTA_A_Username                                     |                                                                                                            | Username                                                                                                                                                                                                                                                 |
| SipAccount.<ipui>.CSTA_A_AuthName                                     |                                                                                                            | Authentication name                                                                                                                                                                                                                                      |
| SipAccount.<ipui>.CSTA_A_AuthPassword                                 |                                                                                                            | Authentication password                                                                                                                                                                                                                                  |
| Broadsoft XSI services                                                |                                                                                                            |                                                                                                                                                                                                                                                          |
| hs.<ipui>.XsiSip                                                      | 0 = No<br>1 = Yes                                                                                          | <b>Use SIP credentials:</b> If activated, the credentials for the user's SIP account (Authentication name and Authentication password) are used.                                                                                                         |
| hs.<ipui>.XsiUsername                                                 |                                                                                                            | <b>Username:</b> Enter a user name for the user access to the menu (max. 22 characters).                                                                                                                                                                 |
| hs.<ipui>.XsiPassword                                                 |                                                                                                            | <b>Password:</b> Enter a password for the user access to the menu (max. 8 characters).                                                                                                                                                                   |
| Feature key synchronization                                           |                                                                                                            |                                                                                                                                                                                                                                                          |
| SipAccount.<ipui>.FeatureKeySyncActive                                | 0 = No<br>1 = Yes                                                                                          | <b>Feature key synchronization:</b> This option permits the users to use keys on their phones to handle Do Not Disturb and Call Forwarding. If activated, the phones synchronise with the BroadWorks Application server on the status of these features. |
| <b>Web-interface: Settings - Mobile devices - Registration Center</b> |                                                                                                            |                                                                                                                                                                                                                                                          |

|                                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                          |
|------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <a href="#">See wiki article.</a>                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                          |
| <b>Web-interface: Settings - Telephony - Audio</b>         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                          |
|                                                            | Audio                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                          |
| DmGlobal.0.<br>WidebandEnabled                             | 0 = Wideband with<br>codec G.722 disabled<br>1 = Wideband with<br>codec G.722 enabled                                                                                                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                          |
| <b>Web-interface: Settings - Telephony - Call settings</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                          |
|                                                            | Call Transfer                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                                                                          |
| Telephony.0.<br>CT_ViaRKey                                 | 0 = No<br>1 = Yes                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>Call transfer via R key:</b> Activated: Users can connect two external callers with each other by pressing the R key. The connections with both parties are terminated.                                               |
| Telephony.0.<br>CT_ByOnHook                                | 0 = No<br>1 = Yes                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>Transfer call by on-hook:</b> Activated: The two participants are connected with one another when the user presses the end call key. The intermediary's connections with the participants are terminated.             |
| Telephony.0.<br>CT_DeriveTargetAddress                     | sipurl<br>sipcontact                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>Determine transfer target address:</b> Select how the transfer target address (Refer-To URI) is to be derived: From transfer target's AOR (Address of Record). From transfer target's transport address (Contact URI) |
|                                                            | Access Code                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                          |
| Telephony.0.<br>AccessCode                                 | max. 3 digits (0 - 9, *,<br>R, #, P)                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>Access Code:</b>                                                                                                                                                                                                      |
| Telephony.0.<br>AccessCodeFor                              | 0x0003 = From<br>incoming calls list<br>0x0150 = From<br>network directory<br>0x0153 = From<br>incoming calls<br>list+From network<br>directory<br>0x1000 = Manual<br>dialing<br>0x7557 = Always                                                                                                                                                                                                                                                                                     | <b>Is added to numbers:</b> Select when the phone numbers should be automatically prefixed with the digits, e.g. when dialling from a call list or a directory.                                                          |
|                                                            | Area Codes                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                          |
| AreaCodes.0.Country                                        | Afghanistan<br>Albania<br>Algeria<br>American_samoa<br>Andorra<br>Angola<br>Anguilla<br>Antigua_and_barbuda<br>Argentina<br>Armenia<br>Aruba<br>Australia<br>Australian_external_territories<br>Austria<br>Azerbaijan<br>Bahamas<br>Bahrain<br>Bangladesh<br>Barbados<br>Belarus<br>Belgium<br>Belize<br>Benin<br>Bermuda<br>Bhutan<br>Bolivia_plural_national_state_of<br>Bonaire_sint_eustatius_and_saba<br>Bosnia_and_herzegovina<br>Botswana<br>Brazil<br>British_virgin_islands | <b>Country:</b> From the option menu select the country or region where your telephone system is to be used . . . the international and national prefix is then entered in the Prefix and Area code fields.              |

Brunei\_darussalam  
Bulgaria  
Burkina\_faso  
Burundi  
Cambodia\_telecom\_cambodia  
Cambodia\_royal\_telecom\_international  
Cameroon  
Canada  
Cape\_verde  
Cayman\_islands  
Central\_african\_rep  
Chad  
Chile\_claro\_chile  
Chile\_vtr\_chile  
Chile\_convergencia\_chile  
Chile\_transam  
Chile\_enewcarriercom\_chile  
Chile\_empresa\_de\_telecomunicaciones\_netonone  
Chile\_heilsberg  
Chile\_concert\_chile  
Chile\_globus  
Chile\_telefonica\_del\_sur  
Chile\_gtd\_manquehue  
Chile\_entel\_larga\_distancia  
Chile\_gsp\_chile  
Chile\_equant\_chile  
Chile\_sur\_telecomunicaciones  
Chile\_astro  
Chile\_stelchile\_sa  
Chile\_micarrier\_telecomunicaciones  
Chile\_fibersat  
Chile\_carrier\_169  
Chile\_impsat\_chile  
Chile\_global\_crossing  
Chile\_netchile  
Chile\_emplresa\_de\_transporte\_de\_senales  
Chile\_hogar\_de\_cristo  
Chile\_movistart  
Chile\_telefonica\_ctc  
China  
Colombia\_movistar  
Colombia\_etb  
Colombia\_une\_epm  
Comoros  
Congo  
Cook\_islands  
Costa\_rica  
Cote\_divoire  
Croatia  
Cuba  
Curacao  
Cyprus  
Czech\_republic  
Dem\_peoples\_rep\_of\_korea  
Dem\_rep\_of\_the\_congo

Denmark  
Diego\_garcia  
Djibouti  
Dominica  
Dominican\_rep  
Ecuador  
Egypt  
El\_salvador  
Equatorial\_guinea  
a  
Eritrea  
Estonia  
Ethiopia  
Falkland\_islands  
\_malvinas  
Faroe\_islands  
Fiji  
Finland  
France  
French\_departments\_and\_territories\_in\_the\_indian\_ocean  
French\_guiana  
French\_polynesia  
Gabon  
Gambia  
Georgia  
Germany  
Ghana  
Gibraltar  
Greece  
Greenland  
Grenada  
Guadeloupe  
Guam  
Guatemala  
Guinea  
Guineabissau  
Guyana  
Haiti  
Honduras  
Hong\_kong\_china  
Hungary  
Iceland  
India  
Indonesia\_indosat  
Indonesia\_telcom  
Indonesia\_bakrie\_telecom  
Iran  
Iraq  
Ireland  
Israel\_kod\_gisha  
Israel\_smile\_tikshoret  
Israel\_netvision  
Italy  
Jamaica  
Japan  
Jordan  
Kazakhstan  
Kenya  
Kiribati  
Korea  
Kuwait  
Kyrgyzstan  
Lao\_pdr  
Latvia  
Lebanon  
Lesotho  
Liberia  
Libya  
Liechtenstein  
Lithuania  
Luxembourg  
Macao\_china  
Madagascar  
Malawi  
Malaysia  
Maldives  
Mali  
Malta

Marshall\_islands  
Martinique  
Mauritania  
Mauritius  
Mexico  
Micronesia  
Moldova\_republic  
\_of  
Monaco  
Mongolia  
Montenegro  
Montserrat  
Morocco  
Mozambique  
Myanmar  
Namibia  
Nauru  
Nepal  
Netherlands  
New\_caledonia  
New\_zealand  
Nicaragua  
Niger  
Nigeria  
Niue  
Northern\_mariana  
s  
Norway  
Oman  
Pakistan  
Palau  
Panama  
Papua\_new\_guinea  
Paraguay  
Peru  
Philippines  
Poland  
Portugal  
Puerto\_rico  
Qatar  
Romania  
Russian\_federati  
on  
Rwanda  
Saint\_helena\_asc  
ension\_and\_trist  
an\_da\_cunha  
Saint\_kitts\_and\_  
nevis  
Saint\_lucia  
Saint\_pierre\_and  
\_miquelon  
Saint\_vincent\_an  
d\_the\_grenadines  
Samoa  
San\_marino  
Sao\_tome\_and\_pri  
ncipe  
Saudi\_arabia  
Senegal  
Serbia  
Seychelles  
Sierra\_leone  
Singapore  
Sint\_maarten  
Slovakia  
Slovenia  
Solomon\_islands  
Somalia  
South\_africa  
South\_sudan  
Spain  
Sri\_lanka  
Sudan  
Suriname  
Swaziland  
Sweden  
Switzerland  
Syrian\_arab\_repu  
blic  
Taiwan\_china  
Tajikistan  
Tanzania  
Thailand

|                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                   |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
|                              | The_former_yugos<br>lav_republic_of_<br>macedonia<br>Timorleste<br>Togo<br>Tokelau<br>Tonga<br>Trinidad_and_tob<br>ago<br>Tunisia<br>Turkey<br>Turkmenistan<br>Turks_and_caicos<br>_islands<br>Tuvalu<br>Uganda<br>Ukraine<br>United_arab_emir<br>ates<br>United_kingdom<br>United_states<br>United_states_vi<br>rgin_islands<br>Uruguay<br>Uzbekistan<br>Vanuatu<br>Vatican<br>Venezuela_boliva<br>rian_republic_of<br>Vietnam<br>Wallis_and_futun<br>a<br>Yemen<br>Zambia<br>Zimbabwe |                                                                                                                                                   |
|                              | International                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                   |
| AreaCodes.0.Int_Prefix       | max. 4 digits, 0-9                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>Prefix:</b> Enter the prefix of the international area code.                                                                                   |
| AreaCodes.0.Int_Code         | max. 4 digits, 0-9                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <b>Area code:</b> Enter the international area code.                                                                                              |
|                              | Local                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |                                                                                                                                                   |
| AreaCodes.0.<br>Local_Prefix | max. 4 digits, 0 - 9                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>Prefix:</b> Enter the prefix of the local area code. These digits are placed in front of the local area code for national long-distance calls. |
| AreaCodes.0.<br>Local_Code   | max. 8 digits, 0 - 9                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>Area code:</b> Enter the local area code for your town/city (depending on country/provider)                                                    |
| AreaCodes.0.<br>UseAreaCode  | 0 = No<br>1 = For local and<br>national calls<br>2 = For Local                                                                                                                                                                                                                                                                                                                                                                                                                          | <b>Use area code:</b>                                                                                                                             |
|                              | Tone Selection                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                   |

|                                                                 |                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Telephony.0.<br>ToneScheme                                      | Austria<br>Belgium<br>Czech<br>Denmark<br>Finland<br>France<br>Germany<br>Greece<br>Retail<br>Italy<br>Netherlands<br>Norway<br>Poland<br>Portugal<br>RUSSIAN_FEDERATION<br>Slovakia<br>Slovenia<br>Spain<br>Sweden<br>Switzerland<br>Turkey<br>UAE<br>UK | <b>Tone scheme:</b> Select the country or region whose ring tones are to be used for your phone from the option menu.                                                                                                                                                                    |
| <b>Web-interface: Settings - Telephony - VoIP</b>               |                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                                          |
|                                                                 | SIP                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                          |
| DmGlobal.0.Port                                                 | Range: 1-65535;<br>Default: 5060                                                                                                                                                                                                                          | <b>SIP port:</b> Enter the SIP port used for VoIP connections.                                                                                                                                                                                                                           |
| DmGlobal.0.TLS_Port                                             | Range: 1-65535;<br>Default: 5061                                                                                                                                                                                                                          | <b>Secure SIP port:</b> Enter the SIP port used for secure VoIP connections (TLS).                                                                                                                                                                                                       |
| dm.local.RtpBasePort                                            | Default: 5004                                                                                                                                                                                                                                             | <b>RTP port:</b> Not available in the web-interface                                                                                                                                                                                                                                      |
| DmGlobal.0.Timers_T1                                            | Default: 500 ms                                                                                                                                                                                                                                           | <b>SIP timer T1:</b> Enter the estimated round trip time of an IP packet between a SIP client and a SIP server (the time it takes between sending out the request to the point of getting a response).                                                                                   |
| DmGlobal.0.<br>Timers_Session                                   | Max. 4 digits, min. 90<br>sec; Default: 1800<br>sec;                                                                                                                                                                                                      | <b>SIP session timer:</b> Defines a session expiry interval: If the session isn't refreshed within the interval, the session is released. Session refresh is started after half of the interval by a re-INVITE message, which the peer side has to confirm to get the session refreshed. |
| DmGlobal.0.<br>Timers_FailedRegistration                        | Max. 4 digits, min. 10<br>sec; Default: 300 sec;                                                                                                                                                                                                          | <b>Failed registration retry timer:</b> Specify after how many seconds the phone should attempt to reregister when the initial registration has failed.                                                                                                                                  |
| DmGlobal.0.<br>Timers_Subscription                              | Default: 1800 s                                                                                                                                                                                                                                           | <b>Subscription timer:</b> Defines the expiration time (in seconds) of a subscription. In order to keep subscriptions effective, subscribers need to refresh subscriptions on a periodic basis.                                                                                          |
| DmGlobal.0.PRACK                                                | 0 = PRACK disabled<br>1 = PRACK enabled                                                                                                                                                                                                                   | <b>PRACK:</b> (Provisional Response Acknowledgement) SIP provisional responses do not have an acknowledgement system so they are not reliable. The PRACK method guarantees a reliable and ordered delivery of provisional responses in SIP.                                              |
|                                                                 | Quality of Service (QoS)                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                          |
| DmGlobal.0.<br>QoS_SIP_DSCP                                     | 0 - 63                                                                                                                                                                                                                                                    | <b>SIP ToS / DiffServ:</b> Enter your chosen QoS DiffServ class for SIP data packets.                                                                                                                                                                                                    |
| DmGlobal.0.<br>QoS_RTP_DSCP                                     | 0 - 63                                                                                                                                                                                                                                                    | <b>RTP ToS / DiffServ:</b> Enter your chosen QoS DiffServ class for RTP data packets.                                                                                                                                                                                                    |
|                                                                 | XSI services                                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                          |
| XSIDir.1.ServerURL                                              |                                                                                                                                                                                                                                                           | <b>Server address</b>                                                                                                                                                                                                                                                                    |
| DmGlobal.0.XSINetdirs                                           | 0 = Off<br>1 = On                                                                                                                                                                                                                                         | <b>Enable XSI directories</b>                                                                                                                                                                                                                                                            |
| DmGlobal.0.<br>XSICallLogs                                      | 0 = Off<br>1 = On                                                                                                                                                                                                                                         | <b>Enable XSI call logs</b>                                                                                                                                                                                                                                                              |
| XSIDir.1.Api                                                    | com.broadsoft.xsi-<br>actions/v2.0                                                                                                                                                                                                                        | Not in web-interface                                                                                                                                                                                                                                                                     |
| <b>Web-interface: Settings - Online directories - Corporate</b> |                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                                          |
|                                                                 | Access to LDAP server                                                                                                                                                                                                                                     |                                                                                                                                                                                                                                                                                          |

|                                                                                                                                                             |                                                                       |                                                                                                                                                                          |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| LDAPDir.0.DirName                                                                                                                                           | Max. 20 characters                                                    | <b>Directory name:</b> Enter a name in the field . This is the name under which the directory will be displayed on the handsets                                          |
| Netdir.<x>.Activated<br><br>0 = LDAP 1, 7 = LDAP 2, 8 = LDAP 3, 9 = LDAP 4, 10 = LDAP 5, 11 = LDAP 6<br>12 = LDAP 7, 13 = LDAP 8, 14 = LDAP 9, 15 = LDAP 10 | 0 = Off<br>1 = On                                                     | <b>Enable directory:</b>                                                                                                                                                 |
| LDAPDir.0.ServerURL                                                                                                                                         | IP address/ DNS name                                                  | <b>Server address:</b> Enter the URL of the LDAP server                                                                                                                  |
| LDAPDir.0.ServerPort                                                                                                                                        | 1 - 65535 (Default: 389)                                              | <b>Server port:</b> Enter the port the LDAP server expects database requests                                                                                             |
| LDAPDir.0.BaseDN                                                                                                                                            | Default: 0, the search starts at the upper area of the LDAP database. | <b>Search base (BaseDN):</b> The LDAP database is hierarchical in design. With the LDAP Search base (BaseDN) parameter, stipulate in which area the search should begin. |
| LDAPDir.0.Username                                                                                                                                          | max. 254 characters                                                   | <b>Username:</b> Enter a global username for the user access to the LDAP director.                                                                                       |
| LDAPDir.0.Password                                                                                                                                          | max. 254 characters                                                   | <b>Password:</b> Enter a global password for the user access to the LDAP directory.                                                                                      |
| LDAPDir.0.TlsMode                                                                                                                                           | 0 = Off<br>1 =<br>2 =                                                 | <b>Secure LDAP:</b>                                                                                                                                                      |
|                                                                                                                                                             | Search in LDAP database                                               |                                                                                                                                                                          |
| LDAPDir.0.StartWithList                                                                                                                                     | 0 = Off<br>1 = On                                                     | <b>Enable List mode:</b> Define what should be initially shown, when the user opens the LDAP directory                                                                   |
| LDAPDir.0.NameFilter                                                                                                                                        | ((cn=*)(sn=*))                                                        | <b>Name filter:</b> The name filter decides which attribute is used for the search.                                                                                      |
| LDAPDir.0.NumberFilter                                                                                                                                      | ( (telephoneNumber=*)(mobile=*))                                      | <b>Number filter:</b> The number filter stipulates the criteria for the automatic completion of telephone numbers.                                                       |
| LDAPDir.0.AdditionalFilter1Name                                                                                                                             |                                                                       | <b>Additional filter #1 name:</b> Enter the name of an additional attribute that will be offered to the user in order to specify the search more detailed.               |
| LDAPDir.0.AdditionalFilter1                                                                                                                                 |                                                                       | <b>Additional filter #1 value:</b> Enter the value for the attribute entered in the corresponding name field.                                                            |
| LDAPDir.0.AdditionalFilter2Name                                                                                                                             |                                                                       | <b>Additional filter #2 name:</b> Enter the name of an additional attribute that will be offered to the user in order to specify the search more detailed.               |
| LDAPDir.0.AdditionalFilter2                                                                                                                                 |                                                                       | <b>Additional filter #2 value:</b> Enter the value for the attribute entered in the corresponding name field.                                                            |
| LDAPDir.0.DisplayName                                                                                                                                       |                                                                       | <b>Display format:</b> In this field you can stipulate how the search result is to be displayed on the handset.                                                          |
| LDAPDir.0.MaxNrOfSearchEntries                                                                                                                              | 50                                                                    | <b>Max. number of search results:</b>                                                                                                                                    |
|                                                                                                                                                             | Configuration of directory items                                      |                                                                                                                                                                          |
| LDAPDir.0.ItemFN                                                                                                                                            |                                                                       | <b>First name</b>                                                                                                                                                        |
| LDAPDir.0.ItemLN                                                                                                                                            |                                                                       | <b>Surname</b>                                                                                                                                                           |
| LDAPDir.0.ItemPH                                                                                                                                            |                                                                       | <b>Phone (home)</b>                                                                                                                                                      |
| LDAPDir.0.ItemPO                                                                                                                                            |                                                                       | <b>Phone (office)</b>                                                                                                                                                    |
| LDAPDir.0.ItemPM                                                                                                                                            |                                                                       | <b>Phone (mobile)</b>                                                                                                                                                    |
| LDAPDir.0.ItemEM                                                                                                                                            |                                                                       | <b>E-mail</b>                                                                                                                                                            |
| LDAPDir.0.ItemFX                                                                                                                                            |                                                                       | <b>Fax</b>                                                                                                                                                               |
| LDAPDir.0.ItemCP                                                                                                                                            |                                                                       | <b>Company</b>                                                                                                                                                           |
| LDAPDir.0.ItemST                                                                                                                                            |                                                                       | <b>Street</b>                                                                                                                                                            |

|                                                           |                                                                                 |                                                                                                                                                                                      |
|-----------------------------------------------------------|---------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| LDAPDir.0.ItemCT                                          |                                                                                 | City                                                                                                                                                                                 |
| LDAPDir.0.ItemZP                                          |                                                                                 | Zip                                                                                                                                                                                  |
| LDAPDir.0.ItemCO                                          |                                                                                 | Country                                                                                                                                                                              |
| LDAPDir.0.ItemAA                                          |                                                                                 | Additional attribute                                                                                                                                                                 |
| LDAPDir.0.IsAdditionalAttributeDialable                   | 0 = Disabled<br>1 = Enabled                                                     | Additional attribute can be dialed:                                                                                                                                                  |
| <b>Web-interface: Settings - Online directories - XML</b> |                                                                                 |                                                                                                                                                                                      |
|                                                           | Public Directory via XML Protocol                                               |                                                                                                                                                                                      |
| XMLDir.0.ProviderName                                     | Public                                                                          | <b>Directory name:</b> Enter a name for the directory. This is the name that will be displayed on the handsets when the user opens the directory list by pressing the directory key. |
| XMLDir.0.ServerURL                                        |                                                                                 | <b>Server address:</b> Enter the URL of the online directory provider.                                                                                                               |
| XMLDir.0.Username                                         |                                                                                 | <b>Username:</b> Enter a global user name for the user access to the online directory.                                                                                               |
| XMLDir.0.Password                                         |                                                                                 | <b>Password:</b> Enter a global password for the user access to the online directory.                                                                                                |
| XMLDir.0.EntCount                                         | 0 = Disabled<br><br>> 0 = Enabled                                               | <b>List update / refresh:</b><br><br><b>Maximum number of entries:</b> Enter the maximum number of entries that are to be downloaded during one reading operation.                   |
| XMLDir.0.NumbFilter                                       | 1 = Office<br><br>2 = Internal<br><br>3 = Mobile<br><br>4 = Home<br><br>5 = Fax |                                                                                                                                                                                      |
| XMLDir.0.HsHasFilter                                      |                                                                                 |                                                                                                                                                                                      |
|                                                           | Public White Pages                                                              |                                                                                                                                                                                      |
| Netdir.4.Activated                                        | 0 = Disabled<br>1 = Enabled                                                     | <b>Enable Public White Pages:</b> Mark the check box if you want to provide the White Pages of the given provider.                                                                   |
| XMLDir.0.WhitePagesDirName                                |                                                                                 | <b>Directory name</b>                                                                                                                                                                |
| XMLDir.0.StartWithListWP                                  | 0 = Editor<br>1 = List                                                          | <b>Start mode</b>                                                                                                                                                                    |
|                                                           | Public Yellow Pages                                                             |                                                                                                                                                                                      |
| Netdir.5.Activated                                        | 0 = Disabled<br>1 = Enabled                                                     | <b>Enable Public Yellow Pages</b>                                                                                                                                                    |
| XMLDir.0.YellowPagesDirName                               |                                                                                 | <b>Directory name</b>                                                                                                                                                                |
| XMLDir.0.StartWithListYP                                  | 0 = Editor<br>1 = List                                                          | <b>Start mode</b>                                                                                                                                                                    |
|                                                           | Public Private pages                                                            |                                                                                                                                                                                      |
| Netdir.6.Activated                                        | 0 = Disabled<br>1 = Enabled                                                     | <b>Enable Public Private Pages</b>                                                                                                                                                   |
| XMLDir.0.PrivatePagesDirName                              |                                                                                 | <b>Directory name</b>                                                                                                                                                                |
| XMLDir.0.StartWithListPP                                  | 0 = Editor<br>1 = List                                                          | <b>Start mode</b>                                                                                                                                                                    |
|                                                           | Corporate Directory via XML Protocol                                            |                                                                                                                                                                                      |
| XMLDir.1.ProviderName                                     |                                                                                 | <b>Directory name:</b> Enter a name for the directory. This is the name that will be displayed on the handsets when the user opens the directory list by pressing the directory key. |

|                                                           |                                                                 |                                                                                                                                                                                      |
|-----------------------------------------------------------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| XMLDir.1.ServerURL                                        |                                                                 | <b>Server address:</b> Enter the URL of the online directory provider.                                                                                                               |
| XMLDir.1.Username                                         |                                                                 | <b>Username:</b> Enter a global user name for the user access to the online directory.                                                                                               |
| XMLDir.1.Password                                         |                                                                 | <b>Password:</b> Enter a global password for the user access to the online directory.                                                                                                |
| XMLDir.1.EntCount                                         | 0 = Disabled<br>> 0 = Enabled                                   | <b>List update / refresh:</b><br><br><b>Maximum number of entries:</b> Enter the maximum number of entries that are to be downloaded during one reading operation.                   |
| XMLDir.1.NumbFilter                                       | 1 = Office<br>2 = Internal<br>3 = Mobile<br>4 = Home<br>5 = Fax |                                                                                                                                                                                      |
| XMLDir.1.HsHasFilter                                      |                                                                 |                                                                                                                                                                                      |
|                                                           | Corporate White Pages                                           |                                                                                                                                                                                      |
| Netdir.1.Activated                                        | 0 = Disabled<br>1 = Enabled                                     | <b>Enable White Pages:</b> Mark the check box if you want to provide the White Pages of the given provider.                                                                          |
| XMLDir.1.WhitePagesDirName                                |                                                                 | <b>Directory name:</b> Enter a name for the directory. This is the name that will be displayed on the handsets when the user opens the directory list by pressing the directory key. |
| XMLDir.1.StartWithListWP                                  | 0 = Editor<br>1 = List                                          | <b>Start mode</b>                                                                                                                                                                    |
|                                                           | Corporate Yellow Pages                                          |                                                                                                                                                                                      |
| Netdir.2.Activated                                        | 0 = Disabled<br>1 = Enabled                                     | <b>Enable Yellow Pages:</b> Mark the check box if you want to provide the Yellow Pages of the given provider.                                                                        |
| XMLDir.1.YellowPagesDirName                               |                                                                 | <b>Directory name:</b> Enter a name for the directory. This is the name that will be displayed on the handsets when the user opens the directory list by pressing the directory key. |
| XMLDir.1.StartWithListYP                                  | 0 = Editor<br>1 = List                                          | <b>Start mode</b>                                                                                                                                                                    |
|                                                           | Corporate Private Pages                                         |                                                                                                                                                                                      |
| Netdir.3.Activated                                        | 0 = Disabled<br>1 = Enabled                                     | <b>Enable Private Pages:</b> Mark the check box if you want to provide the Yellow Pages of the given provider.                                                                       |
| XMLDir.1.PrivatePagesDirName                              |                                                                 | <b>Directory name:</b> Enter a name for the directory. This is the name that will be displayed on the handsets when the user opens the directory list by pressing the directory key. |
| XMLDir.1.StartWithListPP                                  | 0 = Editor<br>1 = List                                          | <b>Start mode</b>                                                                                                                                                                    |
| <b>Web-interface: Settings - Online directories - XSI</b> |                                                                 |                                                                                                                                                                                      |
|                                                           | XSI directory                                                   |                                                                                                                                                                                      |
| DmGlobal.XSINetdirs                                       | 0 = Disabled<br>1 = Enabled                                     | <b>Enable XSI directories</b>                                                                                                                                                        |
| XSIDir.1.StartWithList                                    | 0 = Off<br>1 = On                                               |                                                                                                                                                                                      |
|                                                           | XSI Personal directory                                          |                                                                                                                                                                                      |
| Netdir.20.Activated                                       |                                                                 | <b>Enable Personal directory</b>                                                                                                                                                     |
| XSIDir.1.PDirName                                         |                                                                 | <b>Directory name</b>                                                                                                                                                                |
|                                                           | XSI Group directory                                             |                                                                                                                                                                                      |
| Netdir.18.Activated                                       |                                                                 | <b>Enable Corporate Yellow Pages</b>                                                                                                                                                 |
| XSIDir.1.GDirName                                         |                                                                 | <b>Directory name</b>                                                                                                                                                                |
|                                                           | XSI Group Common directory                                      |                                                                                                                                                                                      |

|                                                                                      |                                 |                                               |
|--------------------------------------------------------------------------------------|---------------------------------|-----------------------------------------------|
| Netdir.19.Activated                                                                  |                                 | Enable Corporate Private Pages                |
| XSIDir.1.GCDirName                                                                   |                                 | Directory name                                |
|                                                                                      | XSI Enterprise directory        |                                               |
| Netdir.16.Activated                                                                  |                                 | Enable Corporate Private Pages                |
| XSIDir.1.EDirName                                                                    |                                 | Directory name                                |
|                                                                                      | XSI Enterprise Common directory |                                               |
| Netdir.17.Activated                                                                  |                                 | Enable Corporate Private Pages                |
| XSIDir.1.ECDirName                                                                   |                                 | Directory name                                |
| <b>Web-interface: Settings - Online Services - Central phonebook</b>                 |                                 |                                               |
| Netdir.21.Activated                                                                  | 0: disabled<br>1: enabled       | Enabled directory                             |
| CentralBook.0.Name                                                                   |                                 | Directory name                                |
| CentralBook.0.<br>ServerURL                                                          |                                 | Server address                                |
| <b>Authentication for<br/>downloading<br/>Central phonebook<br/>via HTTP / HTTPS</b> |                                 | See <a href="#">HTTP(S) Authentication</a>    |
| CentralBook.0.<br>DownloadTime                                                       | 14:00                           | Daily refresh time                            |
| CentralBook.0.<br>MaxSearchResult                                                    | 99                              | Maximum results for central phone-book search |
| CentralBook.0.<br>StartWithList                                                      | 0: No<br>1: Yes                 | Enable list mode                              |
| CentralBook.0.SortBy                                                                 | surname<br>name                 | Sort by                                       |
| CentralBook.0.<br>SearchAnywhereInName                                               | 0: No<br>1: Yes                 | Search anywhere in name?                      |
| <b>Web-interface: Settings - Online Services - XHTML</b>                             |                                 |                                               |
| RapService.< 3-6>.<br>Activated                                                      | 0: disabled<br>1: enabled       | Activate                                      |
| RapService.< 3-6>.<br>Name                                                           |                                 | Name for menu                                 |
| RapService.< 3-6>.<br>SoftkeyName                                                    |                                 | Name for Softkey                              |
| RapService.< 3-6>.<br>ServerURL                                                      |                                 | Server address                                |
| RapService.< 3-6>.<br>UseSIP                                                         | 0: No<br>1: Yes                 | Use SIP credentials                           |
| RapService.< 3-6>.<br>Username                                                       |                                 | Username                                      |
| RapService.< 3-6>.<br>Password                                                       |                                 | Password                                      |
| RapService.< 3-6>.<br>CallConfirm                                                    |                                 |                                               |
| DmGlobal.0.AddSipId                                                                  | 0: No<br>1: Yes                 | Add SipId                                     |
| <b>Web-interface: Settings - System - Web configurator</b>                           |                                 |                                               |
|                                                                                      | Change password                 |                                               |

|                                                                                                                                                                                                                                                 |                                               |                                                                                                                                            |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| WebUIAccounts.1.<br>Password                                                                                                                                                                                                                    |                                               | Change Password > New password (Admin)                                                                                                     |
|                                                                                                                                                                                                                                                 | CLI access via ssh                            |                                                                                                                                            |
| DmGlobal.0.<br>CliPassword                                                                                                                                                                                                                      |                                               | <b>CLI Password (Admin):</b> Enter a password for the administrator access to the configuration via SSH. Value: min. 8, max. 74 characters |
|                                                                                                                                                                                                                                                 | User login                                    |                                                                                                                                            |
| WebUIAccounts.2.<br>Active                                                                                                                                                                                                                      | 0 = deactivated<br>(default)<br>1 = activated | Activate / deactivate Web configurator User login                                                                                          |
| WebUIAccounts.2.<br>Password                                                                                                                                                                                                                    |                                               | Add/Change Password User                                                                                                                   |
| <b>Web-interface: Settings - System - Provisioning and configuration</b>                                                                                                                                                                        |                                               |                                                                                                                                            |
|                                                                                                                                                                                                                                                 | Provisioning and configuration                |                                                                                                                                            |
| Provisioning.global.<br>ProvisioningServer                                                                                                                                                                                                      | max. 255 characters                           | <b>Provisioning server:</b> Enter the URL of your provisioning server in the text field.                                                   |
| Provisioning.global.<br>Period                                                                                                                                                                                                                  |                                               | <b>Provisioning</b> interval set in seconds<br>example: every 24 hours is 86400                                                            |
| <b>Web-interface: Settings - System - Security</b>                                                                                                                                                                                              |                                               |                                                                                                                                            |
|                                                                                                                                                                                                                                                 | Certificates                                  |                                                                                                                                            |
| SystemSettings.global.<br>Security_Certificates_AcceptAllCertificates                                                                                                                                                                           | 0 = No<br>1 = Yes                             | <b>Accept all certificates:</b> Mark the Yes radio button, If you want to accept all certificates.                                         |
|                                                                                                                                                                                                                                                 | HTTP(S) Authentication                        |                                                                                                                                            |
| Security.global.<br>HTTPOAuthUsername                                                                                                                                                                                                           | Max. 74 characters                            | <b>HTTP(S) Authentication:</b> Enter the user name for HTTP(S) authentication.                                                             |
| Security.global.<br>HTTPOAuthPassword                                                                                                                                                                                                           | Max. 74 characters                            | <b>HTTP(S) Authentication:</b> Enter the password for HTTP(S) authentication                                                               |
| <b>Web-interface: Settings - System - System log</b>                                                                                                                                                                                            |                                               |                                                                                                                                            |
| dm.<DM id>.<br>SysLogEnable                                                                                                                                                                                                                     | 0: Off<br>1: On                               | <b>Activate system log:</b>                                                                                                                |
| <p>"DM id", you can see in the web-interface:</p> <ul style="list-style-type: none"> <li>• local (dm.local.SysLogEnable)</li> <li>• dm1 (dm.dm1.SysLogEnable)</li> <li>• dm..</li> <li>• @ for all DECT managers (dm.@.SysLogEnable)</li> </ul> |                                               |                                                                                                                                            |
| dm.local.SysLogServer<br>dm.@.SysLogServer                                                                                                                                                                                                      | max. 240 characters                           | <b>Server address:</b> Enter the IP address or the (fully qualified) DNS name of your Syslog server. Value:                                |
| dm.local.SysLogServerPort<br>dm.@.SysLogServerPort                                                                                                                                                                                              | Range: 1-65535;<br>Default: 514               | <b>Server port:</b> Enter the port number, where the Syslog server expects to receive requests.                                            |
| dm.local.SysLogProtocol<br>dm.@.SysLogProtocol                                                                                                                                                                                                  | tcp<br><br>udp                                | <b>SyslogProtocol</b><br><br>In software 2.36 this setting can't be changed via provisioning, this will be changed.                        |

|                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                      |
|---------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| dm.local.SysLogTlsEnable                                | 0: Off<br>1: On                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                      |
| dm.@.SysLogTlsEnable                                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                      |
| SystemSettings.global.DebugLevelMask                    | DWEI                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | D = debug<br>W = warning<br>E = error<br>I = info                                                                                                                                                                    |
| Not possible via provisioning                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <b>SNMP manager address:</b> Enter the IP address of the SNMP manger.                                                                                                                                                |
| Not possible via provisioning                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <b>SNMP manager port:</b> Enter the port number                                                                                                                                                                      |
| <b>Web-interface: Settings - System - Date and time</b> |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                      |
|                                                         | Date and time                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                                                                                      |
| DmGlobal.0.NtpServer                                    | 0.europe.pool.ntp.org,<br>1.europe.pool.ntp.org,<br><br>2.europe.pool.ntp.org,<br>3.europe.pool.ntp.org                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>Time server:</b> There are some common time servers preset in the field. Enter your preferred time server in the text field. Multiple time servers can be entered separated by commas. Value: max. 255 characters |
| DmGlobal.0.TimeZone                                     | value="Pacific/Midway"<br>value="Pacific/Niue"<br>value="Pacific/Pago_Pago"<br>value="Pacific/Samoa"<br><br>value="Pacific/Honolulu"<br>value="Pacific/Johnston"<br>value="Pacific/Rarotonga"<br>value="Pacific/Tahiti"<br>value="Pacific/Marquesas"<br>value="America/Anchorage"<br>Pacific/Gambier"<br>value="America/Los_Angeles"<br>Pacific/Pitcairn"<br>value="America/Denver"<br>value="America/Chicago"<br>Pacific/Easter<br>Pacific/Galapagos"<br>value="America/New_York"<br>value="America/Caracas"<br>value="America/Sao_Paulo"<br>value="Europe/Belfast"<br>value="Europe/Dublin"<br>value="Europe/Guernsey"<br>value="Europe/Isle_of_Man"<br>value="Europe/Jersey"<br>value="Europe/Lisbon"<br>value="Europe/London"<br>value="Greenwich"<br>value="Europe | <b>Time Zone:</b>                                                                                                                                                                                                    |

/Amsterdam"  
value="Europe  
/Andorra"  
value="Europe  
/Belgrade"  
value="Europe  
/Berlin"  
value="Europe  
/Bratislava"  
value="Europe  
/Brussels"  
value="Europe  
/Budapest"  
value="Europe  
/Busingen"  
value="Europe  
/Copenhagen"  
value="Europe  
/Gibraltar"  
value="Europe  
/Ljubljana"  
value="Europe  
/Luxembourg"  
value="Europe  
/Madrid"  
value="Europe  
/Malta"  
value="Europe  
/Monaco"  
value="Europe  
/Oslo"  
value="Europe  
/Paris"  
value="Europe  
/Podgorica"  
value="Europe  
/Prague"  
value="Europe  
/Rome"  
value="Europe  
/San\_Marino"  
value="Europe  
/Sarajevo"  
value="Europe  
/Skopje"  
value="Europe  
/Stockholm"  
value="Europe  
/Tirane"  
value="Europe  
/Vaduz"  
value="Europe  
/Vatican"  
value="Europe  
/Vienna"  
value="Europe  
/Warsaw"  
value="Europe  
/Zagreb"  
value="Europe  
/Zurich"  
value="Africa  
/Cairo"  
value="Europe  
/Athens"  
value="Europe  
/Bucharest"  
value="Europe  
/Chisinau"  
value="Europe  
/Helsinki"  
value="Europe  
/Kaliningrad"  
value="Europe  
/Kiev"  
value="Europe  
/Mariehamn"  
value="Europe  
/Nicosia"  
value="Europe  
/Riga"  
value="Europe  
/Sofia"  
value="Europe

|                                                                                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                          |
|-------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
|                                                                                           | /Tallinn"<br>value="Europe<br>/Tiraspol"<br>value="Europe<br>/Uzhgorod"<br>value="Europe<br>/Vilnius"<br>value="Europe<br>/Zaporozhye"<br>value="Europe<br>/Istanbul"<br>value="Europe<br>/Kirov"<br>value="Europe<br>/Minsk"<br>value="Europe<br>/Moscow"<br>value="Europe<br>/Simferopol"<br>value="Europe<br>/Volgograd"<br>value="Asia<br>/Dubai"<br>value="Europe<br>/Astrakhan"<br>value="Europe<br>/Samara"<br>value="Europe<br>/Ulyanovsk"<br>value="Asia<br>/Karachi"<br>value="Asia<br>/Dhaka"<br>value="Asia<br>/Hong_Kong"<br>value="Asia<br>/Tokyo"<br>value="Australia<br>/Adelaide"<br>value="Australia<br>/Darwin"<br>value="Australia<br>/Brisbane"<br>value="Australia<br>/Sydney"<br>value="Pacific<br>/Noumea" |                                                                                                                          |
| DmGlobal.0.<br>NtpEnableLocalServer                                                       | 0 = No<br>1 = Yes                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | <b>Act as Local Time Server:</b> In case the internet time servers are not available you can set the time manually.      |
| <b>Web-interface: Settings - System - Firmware</b>                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                          |
|                                                                                           | System firmware                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                          |
| FwUpdateUrl<br><br>must be placed in<br><oper.. see <a href="#">wiki</a>                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | <b>URL to firmware file:</b> In the text field specify the URL of the configuration server where the firmware is located |
| FwUpdateStart<br><br>must be placed in<br><oper.. see <a href="#">wiki</a> for an example | 0 = Immediately<br>Unix time stamp (See<br><a href="https://www.epochconverter.com/">https://www.<br/>epochconverter.com/</a><br>)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | <b>Planned schedule:</b>                                                                                                 |
| <b>Settings - System - DECT settings</b>                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                                                                                                          |
|                                                                                           | Eco DECT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |                                                                                                                          |
| DmGlobal.0.<br>DECTEcoMode                                                                | 0 = Maximum range<br>1 = Limited range                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | <b>DECT Radiation power:</b> Set the DECT radiation power to your needs:                                                 |
|                                                                                           | DECT security settings                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                          |
| DmGlobal.0.<br>DECTCipherDisable                                                          | 0 = Activate<br>1 = Deactivate                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | <b>DECT Encryption:</b> Activate/deactivate the option.                                                                  |

|                                                    |                                                                                                                                                                                                |                                                                                                       |
|----------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| DmGlobal.0.<br>DECTEnhancedEncryption              | 0 = Deactivate<br>1 = Activate                                                                                                                                                                 | <b>Enhanced Security - Early Encryption and Re-Keying:</b> Activate/deactivate the option             |
| DmGlobal.0.<br>DECTReleaseUnencrypted              | 0 = Deactivate<br>1 = Activate                                                                                                                                                                 | <b>Enhanced Security - Automatic release for non-encrypted calls:</b> Activate/deactivate the option. |
| DECT Radio settings                                |                                                                                                                                                                                                |                                                                                                       |
| DmGlobal.0.<br>SystemRegDomain                     | EUR = Europa<br>LAM = Latin America<br>BRA = Brazil<br>SEA = South East Asia                                                                                                                   | <b>DECT Radio band:</b> Select the radio frequency band used in your region.                          |
| <b>Hidden Parameters</b>                           |                                                                                                                                                                                                |                                                                                                       |
| DmGlobal.0.<br>bLedSignallingActive                | 0 = LED's off<br>1 = LED's on                                                                                                                                                                  | Possibility to turn the LED's on the base Off or On.                                                  |
| DmGlobal.<br>EnableDFFlagForSipPackets             |                                                                                                                                                                                                |                                                                                                       |
| Netdir.<x>.<br>CachingType                         | For value x see: <a href="#">FAQ N870 - Directories number list</a>                                                                                                                            | <a href="#">Lookup caching policy</a>                                                                 |
| SipProvider.<0-19>.<br>RenewConnectionAfterTimeout | 0 = off<br>Range = 1- 30 minutes (30 = default)                                                                                                                                                | For more info see: <a href="#">FAQ - Auto provisioning: Failed registration monitor</a>               |
| SipProvider.<0-19>.<br>ConnectionTimeoutAction     | 0 = transport restart (default)<br>1 = application restart                                                                                                                                     | For more info see: <a href="#">FAQ - Auto provisioning: Failed registration monitor</a>               |
| dm.X.<br>ScheduledRebootDays                       | X = dm name or @ for all dm's<br><br>never = off (default)<br>0 = Sunday<br>1 = Monday<br>2 = Tuesday<br>3 = Wednesday<br>4 = Thursday<br>5 = Friday<br>6 = Saturday<br>Value is "," separated | For more info see: <a href="#">FAQ - Auto provisioning: Scheduled reboot</a>                          |
| dm.X.<br>ScheduledRebootTime                       | X = dm name or @ for all dm's<br><br>Format = HH:MM<br>(4.00 = default)                                                                                                                        | For more info see: <a href="#">FAQ - Auto provisioning: Scheduled reboot</a>                          |