FAQ Maxwell - Call Pickup

Introduction

Call Pickup is a feature that allows one to answer someone else's telephone call. The feature is accessed by pressing a blinking Busy Lamp Key (BLF), or by pressing a special sequence of buttons on the Gigaset phone (Feature code).

From software 2.23, you can configure a different Call Pickup code using the "|" symbol at the end.

Valid for Maxwell					
Basic	2	3	4		

Call Pickup using BLF key

On the Gigaset desktop devices you can configure Busy Lamp Field (BLF) keys, when these keys are blinking and pressed a Call Pickup for this incoming call is done.

Example 1: Mostly used by many platforms.

Call Pickup Code = *04

- 1. User 1011 is receiving an incoming call.
- 2. The BLF key 1011 on the device with number 1012 is blinking.
 3. User 1012 presses
- the blinking BLF key
- 4. Maxwell sends invite <

Provisioning Function Key 1011 1: 1011 Basic **BLF** Function BLF Connection 1012 Target number 1011 Call Pickup Code *04 Display Name 1011 Basic LED colour Red Yellow Green Standard

No Auto

Call Pickup Code> + <Target number>, in this example: Request-Line: INVITE sip:*041011@x.x.x.x SIP/2.0

Example 2: Call Pickup code is not using the Target number.

In some platforms, the Monitored number (Target number) is an user-ID and not a phone number, but the Call Pickup is using the phone number. So the Call Pickup code needs to be different.

- User1011 must be monitored using the user-ID and not his /her internal number 1011
- The Call Pickup must use the <Call Pickup Code> + <Target number>
- 1. User 1011 is receiving an incoming call.
- 2. The BLF key User1011 on the device with number 1012 is blinking.
- 3. User 1012 presses the blinking BLF key
- 4. Maxwell sends invite *041011

			/			
Key	Functi	ion		No Au Provi	uto sioning	
1: 1011 Basic	BLF		User1011			~
Function		BLF	•			
Connection		1012	•			
Target number		User1011				
Call Pickup Code		*041011				
Display Name		1011 Basic				
LED colour		Red	/ellow	Green	Sta	andard

Call Pickup code	Maxwell sends	Example:
Without " " as END character (Normal behavior)	<call code="" pickup=""> + <target number=""></target></call>	*04
With " " as END character	<call code="" pickup=""> without the " "</call>	*041011