FAQ - How many devices do you need

Introduction

How many devices you need depends on.

- DECT Measurement
- Call Capacity
- Number of handsets
- Codec used

System	Integrator + Manager + Base	Integrator + Manager	Base	Maximum number of handsets	Maximum number of Parallel calls
Small	1		2 - 9	50	20
Medium		1	1 - 60	250	60



if you need more then:

- 50 Handsets
- 20 Parallel calls
- 10 Base stations

You switch from Small to Medium size system and the Integrator + Manager is not an DECT base anymore, so you need one extra device. There is no license needed.