

FAQ Maxwell - Syslog

Introduction

Web-interface: **http://<IP address>/#/Expert**

Login as **admin** and switch to the above URL.

Valid for Maxwell			
Basic	2	3	4

Syslog to Server

On setting the switch to "YES" you are able to configure a syslog server URL / IP address.
Per default the standard port "514" is used for the communication.
You can change the port by using is within the syslog server setting.

e.g. <http://192.168.0.90:520>

Sys Dump

For SysDump currently the download to the connected PC is supported, only. The download file is stored locally on the PC and can be send to Gigaset Support via Mail.

The SysDump file is password protected.

SETTINGS

STATUS

EXPERT

Network

Audio

Debugging

Reboot

System Logging

Door Interphone

Statistics

Syslog to Server

Activate syslog

Syslog server

Sys Dump

Send to PC

Set

Cancel

Auto provisioning

Parameter	
System.Syslog.RemoteLogging.Enabled	Activate Remote Syslog 0 = Disabled 1 = Enabled
System.Syslog.RemoteLogging.Server	URL to the syslog server
System.Syslog.RemoteLogging.Server.Port	Syslog server port (514)