FAQ - User agent

Valid for:	N610	N670	N870	N870E	Embedded Integrator	Virtual Integrator

Introduction

See below for a user-agent example.

This is seen in:

1. SIP messages
2. HTTP(s) messages

Device	User-Agent:
N870	Gigaset N870 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX
N870E	Gigaset N870E IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX
N670	Gigaset N670 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX
N610	Gigaset N610 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX

From software 2.26 we have added capacity information to the HTTP(s) user agent only.

Platforms that do auto-provisioning can use this information to block the administrator to add more handsets than supported by the system.

Device			User-Agent:
N870	Single Cell / Small		User-Agent: Gigaset N870 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=50
	Medium		User-Agent: Gigaset N870 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=250
	Embedded Integrator	0 DM	User-Agent: Gigaset N870 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=0
		1 DM	User-Agent: Gigaset N870 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=250
		2 DM	User-Agent: Gigaset N870 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=500
		...	...
N870 E	Same as N870 (Above) but with "E"		User-Agent: Gigaset N870E IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=250
N670	Single Cell		User-Agent: Gigaset N670 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=20
N610	Single Cell		User-Agent: Gigaset N610 IP PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=8
N870	Virtual Integrator	0 DM	User-Agent: Gigaset N870 VI PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=0
		1 DM	User-Agent: Gigaset N870 VI PRO/83.V2.43.0+build.5f0a106;7C2F80XXXXXX;Handset=250
		...	...

Remove Handset capacity information

Via auto-provisioning, it is possible to disable the capacity information in the HTTP(s) user-agent.

Auto-provisioning example	User agent

Disable Handset capacity information
`<?xml version="1.0" encoding="UTF-8"?>`
`<provisioning version="1.1" productID="e2">`
`<nvm>`
 	
`<!-- 0 = Do not add capacity information, 1 = Add capacity information -->`
`<param name="Provisioning.global.CapacityInformation" value="0" />`
 	
`</nvm>`
`</provisioning>`
	User-Agent: Gigaset N610 IP PRO/83.V2.43.0+build.5f0a106; 7C2F80XXXXXX

Enable Handset capacity information
`<?xml version="1.0" encoding="UTF-8"?>`
`<provisioning version="1.1" productID="e2">`
`<nvm>`
 	
`<!-- 0 = Do not add capacity information, 1 = Add capacity information -->`
`<param name="Provisioning.global.CapacityInformation" value="1" />`
 	
`</nvm>`
`</provisioning>`
	User-Agent: Gigaset N610 IP PRO/83.V2.43.0+build.5f0a106; 7C2F80XXXXXX;Handset=8

Remove MAC address and Handset capacity information

Via auto-provisioning, it is possible to remove the MAC address and the Handset capacity information in the SIP / HTTP(s) user-agent.

Auto-provisioning example	User agent

Disable capacity information
`<?xml version="1.0" encoding="UTF-8"?>`
`<provisioning version="1.1" productID="e2">`
`<nvm>`
 	
`<param name="SystemSettings.global.UseCommonUA" value="1" />`
`<param name="Provisioning.global.MACAddressInformation" value="0" />`
`<param name="Provisioning.global.CapacityInformation" value="0" />`
 	
`</nvm>`
`</provisioning>`
	User-Agent: Gigaset N610 IP PRO/83.V2.43.0+build.5f0a106