Maxwell Expansion Module

Introduction

Hardware:

- Can be connected to Maxwell Basic, 2, 3 and 4, Software 2.15.9 or higher
- 7 inch FSTN display
- 30 Keys - 15 per row
- Bicolor (red/green) LED's for signaling
- 3 colors (red/yellow/green)
- Connect up to 3 devices in series
- Power Socket (use the recommended Power supply only)
- RJ12 for the connection to the Main Device
- RJ45 for the connection to the next Expansion Module
- Part number: S30853-H4061-R101

Software:

- Up to 58 functions on 2 pages
- Self labeling
- Auto-provisioned

Device Firmware

The device firmware will be updated automatically, if necessary, via Maxwell Basic, 2, 3 or 4. The firmware image of the Expansion Module is included in the firmware image of the Maxwells to ensure, that always a valid firmware base for interconnection is available.

Power supply

You need to order one power supply (L36280-Z4-X765), this is not included, One power supply is always needed, also when the Maxwell phone is using a Power supply. With one power supply you can connect up to 3 Expansion modules.

FAQ

Datasheet