

FAQ - Disinfectant resistance

How to clean and disinfect your Gigaset pro handset

Gigaset professional DECT handsets [S650H PRO](#), [SL750H PRO](#), [S700H PRO](#), [SL800H PRO](#), [R700H PRO](#) are optimized for everyday business. They are part of the DECT IP multicell- and single cell solutions N870 and N670. Gigaset helps supermarkets, construction markets and medical practices across Europe to optimize their communication solutions.

1. Be sure that your hands are cleaned and disinfected
2. Before disinfection, pre- clean your Gigaset Pro device to remove dust
3. You are free to use liquid disinfection solutions or cleaning wipes
4. Apply the liquid disinfection solution carefully, using a non-abrasive cloth



Disinfectant res...pro handsets.pdf

List with disinfectants

Disinfectant	Manufacturer	S650H PRO	SL750H PRO	R650H PRO	S700H PRO	SL800H PRO	R700H PRO
AHD 2000	Dr. Hans Rosemann	•	•	-	•	•	•
Sterilium classic	Bode	•	•	-	•	•	•
Epicare disinfectant	Ecolab	•	•	-	•	•	•
Desdermann pure	Schülke	•	•	-	•	•	•
CIMO Sept	Dr. Schnell	•	•	-	•	•	•
Samolind	Dr. Schnell	•	•	-	•	•	•
Samtasan	Dr. Schnell	•	•	-	•	•	•
Spitacid	Ecolab	•	•	•	•	•	•
Incidin Rapid	Ecolab	•	•	•	•	•	•

This selection is intended to be a representative sample.

The above handsets are probably resistant to most other common disinfectants used in healthcare, but this cannot be guaranteed.