FAQ Maxwell - Broadsoft Remote office

Introduction

Broadsoft Remote Office allows you to use your home phone, your cell phone or even a hotel phone as your business phone. This service also directs all calls coming to your business phone to ring the remote office phone.

This feature is available using software 2.20 or higher.

	Valid for Maxwell		
Basic	2	3	4

Maxwell 2 & 3

Configuration

In the Maxwell web-interface you need to Enable the Remote Office Feature.

Go to: **SETTINGS - Telephony - Phone System - Remote office**

Remote Office

|	
Use remote office	Yes / No
Remote office number	3612

> ⓘ **Improvement**
>
> Current you need to add the Remote office number, and then when you press save, remote office using this number is enabled on the platform and all calls are forwarded to this number. To disable go into the MMI to switch off this feature.
>
> We will change in an upcoming release that the function is not be default enabled but only enables the "Remote office" menu in the Maxwell phone.

Open the Maxwell Phone menu pressing the Center key ☐ ✓ - **Select Services - Remote Office**.

You can change the status between **Off** and **On**.

When enabled, you can enter the Phone number.

The feature is enabled on the Broadsoft platform.

Remote Office

Remote Office allows you to use your home phone, your cell phone or even a hotel phone coming to your business phone to ring the remote office phone.

OK	Apply	Cancel

Remote Office: ☐ On ◉ Off

* Remote Phone Number / SIP-URI: 3610

OK	Apply	Cancel

This functionality is mostly enabled via Broadsoft auto provisioning, see below for the provisioning parameters.

Parameter	Description
Telephony.PhoneSystem.Broadsoft.RemoteOffice.Enabled	0 = Disabled 1 = Enabled
Telephony.PhoneSystem.Broadsoft.RemoteOffice.Number	You need to enter a number
Example: <param name="Telephony.PhoneSystem.Broadsoft.RemoteOffice.Enabled" value="1"/> <param name="Telephony.PhoneSystem.Broadsoft.RemoteOffice.Number" value="3611"/>	