

FAQ Maxwell - Reboot

Introduction

You can reboot the phone via:

- Web-interface
- Phone menu
- Provisioning, check-sync


| | | | |
|-------------------|---|---|---|
| Valid for Maxwell | | | |
| Basic | 2 | 3 | 4 |

Web interface

Via the web-interface you can restart the phone.

Go to: **Settings - System - Reboot and Reset**



From software 2.13 or higher, the reboot option is also available for the user login.



Phone menu

From software 2.13 or higher, the reboot option is also available via the phone menu:

Go to: **Settings - Reboot**

| Maxwell 4 | Maxwell 3/2 |
|---|---|
|  A screenshot of the 'SETTINGS' menu on a Maxwell 4 device. The menu is dark-themed with white text. At the top is a back arrow and the word 'SETTINGS'. Below are four items: 'VLAN VLAN' with a right arrow, 'Reset' with a circular arrow icon and a right arrow, 'Reboot' with a power button icon and a right arrow, and 'Info' with an information icon and a right arrow. |  A screenshot of the 'Settings' menu on a Maxwell 3/2 device. The menu is dark-themed with white text. At the top is the word 'Setti'. Below are five items: 'PIN', 'VLAN', 'Reset', 'Reboot' (highlighted with a blue bar), 'Info', and 'Back' at the bottom with a right arrow. |

Auto provisioning

See: [SIP message - provisioning](#)