

# Maxwell 10 Build 2.5.33.1

## Release Notes

### Release Date:

17.05.2017

### Version:

2.5.33.1

### Improvements

- Update of Android security patches
- Unify approved
- Incoming calls accumulated by callers
- Bigger and faster programmable key widget
- Enhanced ringtone settings - external, internal and group ringtones selectable

### Bugfixes

- Call transfer started if END key is pressed on Maxwell during consultation call
- Missed call melody not turns off when call waiting is over
- Translation issues fixed
- elmeg IP 680 matters corrected
- Call list date correction
- Many additional issues were fixed

### Information

Due to technical design, wireless LAN and Bluetooth Audio should not be used simultaneously

Download

Software versions	
Android	5.1.1
DVF9919	03.641a
Build number	80_1_2.5.33.1

## Firmware update

### Important


Due to the fact, that Android-5.1 requires a lot of more memory than older Android versions we recommend to insert an [external SD-card](#), or plug in an USB-stick with minimum 2GB free memory space, at least during the upgrade phase!

There are 3 options to upgrade.

## Option 1: Two step Method using an SD-card or USB-memory-stick.

1. Plug in an SD-card or USB-stick with at least 2GB free memory (or enter an external SD card). Then start the Maxwell-10 WEB-UI (click on the Web Server Address - shown in the Maxwell 10 under "Settings=>WebUI - log in (Standard Password is "admin") and follow exactly the following 3 steps:

2. In the web-interface go to: *System - Firmware Update* page and check if the *Data server* field is (default) [profile.gigaset.net/device](http://profile.gigaset.net/device)



The screenshot shows a dark-themed web interface. On the left, the text 'Data server' is displayed. To its right is a text input field containing the URL 'profile.gigaset.net/device'. Below the input field, there is a smaller text label that reads '..set custom url here'. To the right of the input field is a button labeled 'Update firmware'.


3. Press "Save"
4. Press "Update firmware"

The update will be done in 2 steps.

1. Upgrade to new Jelly Bean software with USB drivers upgrade to support the USB memory extension.
2. Upgrade to Lollipop.

## Option 2: One step method using external SD-card.

1. Enter an [external SD-card](#) (or plug in an USB-stick).
2. Download the software via the "Download" button on this page.
3. Unpack the zip file. You will get a .txt file with the Open Source License text and an encrypted zip file which is your firmware image.
4. In the web-interface go to: *System - Firmware Update* page and select the above extracted zip file.



The screenshot shows a dark-themed web interface. On the left, the text 'User-defined firmware file' is displayed. To its right is a text input field. Below the input field, there is a smaller text label that reads '..set custom url here'. To the right of the input field are two buttons: 'Bladeren..' and 'Load'.

5. Start the upgrade.

## Option 3: One step method without external SD-card.

1. Do a [factory reset](#) of the Maxwell 10 to free all memory for firmware update.
2. Download the software via the "Download" button on this page.
3. Unpack the zip file. You will get a .txt file with the Open Source License text and an encrypted zip file which is your firmware image.
4. In the web-interface go to: *System - Firmware Update* page and select the above extracted zip file.



The screenshot shows a dark-themed web interface. On the left, the text 'User-defined firmware file' is displayed. To its right is a text input field. Below the input field, there is a smaller text label that reads '..set custom url here'. To the right of the input field are two buttons: 'Bladeren..' and 'Load'.

5. Start the upgrade.